


Contents



Breva 1100

- Aspects and vehicle characteristics
- General data
- Dashboard and immobilizer
- Electronic injection, description and functioning
- Engine
- New electro-mechanical components
- Diagnosis - Axone
- Balancing throttle bodies


Aspect and vehicle characteristics



Aspect and vehicle characteristics



Total view of vehicle :
dimensions



Aspect and vehicle characteristics



General data

Weight: 248 Kg

Output: max. KW 63,0 at 7500 rpm

Torque: Nm 85,0 a 6800 rpm

Maximum speed in 6th gear 210 Km/h

Front tire: 120/70 ZR17 (58W) pressure 1/2 persons 250kPa±10

Rear tire: 180/55 ZR17 (73W) pressure 1/2 persons 280kPa±10

Injection/ignition system MAGNETI MARELLI


Computer IAW 5AM2 with map alfa/n

Aspect and vehicle characteristics



Frame


ZGULP...



Aspect and vehicle characteristics



Fuel tank




Capacity	23 l ± 0,5 l
Material	Nylon

Aspect and vehicle characteristics




Front brakes

Double calipers and discs



Rear brakes





Aspect and vehicle characteristics




Additional equipment.

Accessories (optional):


- Windscreen;
- Carrying Case adjustable in height;
- Side bags
- Alarm systems (not yet available)



Dashboard



Dashboard : identifying areas



Rev counter:


Positioned at the left, final range 10.000 rpm.

At the end of the scale is a red warning light (Led) without monogram to indicate to shift gear when surpassing a preset level rpm. The rpm activation level can be adjusted via the users interface.

Dashboard : identifying areas



Speedometer at the center



Fuel level indicator Under the fuel warning light sits a red warning light without pictogram (Led) for the eventual alarm system.

Multifunctional Display

Dashboard : identifying areas



Fuel level indicator

The dashboard is connected to a variable resistor. Measurements that fall out of the normal operating range are considered as faults and are signalled by the diagnostics. The indications show at the instrument panel at the right and the spare indicator underneath.

The characteristics and measurement curve can be found in the repair manual.

•	Quantity	LITRES	OHM
•	8/8	22.50	10-20 appr.
•	4/8	11.25	100 appr.
•	0	0	250-300 appr.

The spare indicator lights up at values higher than 230 ohm

After 2 km it shows the amount of km driven after the indicator light came on.

Dashboard : identifying areas



Led indicators

From left to right:

- Indicator green, left hand indicator
- Indicator orange, ABS faulty (CURRENTLY NOT ACTIVE)
- Indicator red, Alarm: engine oil pressure problem, EFI and w/ vehicle OFF indicator immobilizer.
- Indicator green, Neutral position
- Indicator yellow, vehicle stand down
- Indicator blue, beam lights on
- Indicator green, right hand indicator



Dashboard: indicators and lights



Direction indicators.

- The dashboards controls the indicator lights, as well for the single indications left and right as for the combined circuits for the “Hazard” function.
- Indications for problems with circuits (bulb burnt or short circuited) by doubling the flashing frequency of the warning light and with indication on the dashboard left or right



Activation/deactivation of the Hazard function

This function can only be activated or deactivated with the key in ON position

Control of beam lights

The light relay will only be operated by the engine ECU when the rpm exceeds 800

Dashboard: selections



The commands to move between various dashboards functions are obtained by a three position selector at the light switch at the left hand steering handle.

The selector has following three positions:

- Trip 1
- Trip 2
- Mode



In the first position will show the data of TRIP1,

In the second the data of TRIP2

While in the third position MODE, one can access to the functions of dashboard configurations.



Dashboard: display



Basic information

- On the display appear as well the basic information as the information activated by the selector position. These are:
- Clock. Clock settings can be 12 or 24 hour indications, where 12 hour indications show AM or PM.
- Odometer. A 6 digit number in km or miles, according to user selection.
- Ambient temperature. Shows in the upper left corner of the LCD. When the temperature is close to zero, a icing symbol will show (next slide). Finally one can show the temperature in °C or °F selectable by the user.

Clock Display






Dashboard: display



Handles heater (OPTIONAL)

With engine running, by pressing insisting at command handles heating, an icon will show at the display that substitutes the selected trip indication. That will be transferred to the central part of the display. With every short pulse a three positions bar will grow indicating the power level present in the handles heating. When the engine is stopped the heater will be switched off. At the next vehicle usage the handles heater will reposition at the ultimate setting.



Dashboard: immobilizer



- ➔ The immobilizer system is integrated in the electronic dashboard.
- ➔ At key-to-ON the dashboard will read the key code. If the code corresponds to the one memorized, the dashboard will activate the initial check and will allow the ECU for engine starting, via the CAN Bus line.
- ➔ If the key code is not recognized, the dashboard will not permit for engine starting and on the display will appear the request to insert the code to allow for “manually” engine starting.
- ➔ To the customer will be delivered two keys with transponder, already memorized from the factory and at every key-to-ON the dashboard will ask to insert the personal 5 digit code, if not yet done:

you must remember to insert the user code

- ➔ To insert the personal code one must select the function **CODE MODIFICATION**

Dashboard : display



Trip 1-2

In these two positions of the display are demonstrated the data relevant for trips 1 and 2.

In the central area is constantly displayed the partial distance covered while in the lower portion the following data will be shown in rotation:

- Trip time
- Average Fuel consumption of the trip
- Current consumption
- Maximum speed
- Average speed

A short pulse will change the indications between one and the other, keeping the switch pressed longer will reset all values to zero for the selected trip.

Consumption is expressed in litres per 100 kilometres or in miles per gallon

For detailed functioning please read with attention the workshop manual information.

Dashboard : MODE



Mode


in this position you can select the other functions of the dashboard with the vehicle stopped and thus with speed equal to Zero with every short pulse of the switch SET you can see in sequence the following functions:

stopwatch

battery voltage

Menu

The selection of the functions is affected by holding the SET switch for a longer period.



For detailed functioning of the stopwatch please read with attention the workshop manual

Dashboard :Menu



Access to this function is only possible with the vehicle stopped .The graphic of this menu is as follows:



To move your selection down-wards,a short pulse of the switch is sufficient

Pressing the switch down for longer gives the confirmation of your selection of the relative item.

Dashboard : Settings



SETTINGS

When the settings menu is selected, which can also be done by the driver or bike owner, a drop-down menu shows:

Exit

Adjust Clock

Change gear shift rpm

°C/°F

12H/24/

Led immobiliser (turn off when installing the optional alarm system)

Change code

Recover code

For detailed functioning please read with attention the workshop manuals

Dashboard : Settings



Change CODE

In case one remembers its own code is sufficient to insert it and in sequence we will insert the new code which will automatically be memorised.

In case of a new vehicle the user code is: 00000

Recover CODE

In case one does not remember its own code and wishes to modify it, it is requested to insert the two keys that are memorised. The first one is already inserted and therefore it is requested to insert the second key with the message: **INSERT 2ND KEY**

If the second key is not inserted within 20 seconds the operation will terminate.

After its recognition it will be requested to insert a new code with the message: **INSERT THE NEW CODE**

At the end of the operation the dashboard will return to the menu **Settings**.

Dashboard: DIAGNOSTICS



DIAGNOSTICS

To enter in this menu, that will operate on the diagnostic functions and therefore the access is reserved to the *technical assistance*, a code is requested.

Appears the text: INSERT SERVICE CODE

For the Breva 1100 this is: **36421**

The functions in this menu are:

Exit

Faults ECU

Faults dashboard

Cancel Fault codes

Reset Service

Update

Change keys

Dashboard : DIAGNOSTICS



FAULTS ECU. The dashboard receives from the central computer only actual faults

Description	Error code
Error throttle valve C.C. Vcc	ECU 10
Error throttle valve C.C. Gnd	ECU 11
Error Engine temperature C.C. Vcc	ECU 14
Error Engine temperature C.C. Gnd	ECU 15
Error Air temperature C.C. Vcc	ECU 16
Error Air temperature C.C. Gnd	ECU 17
Error Low battery	ECU 20
Error Lambda sensor	ECU 21
Error Ignition coil 1 C.C. Vcc	ECU 22
Error Ignition coil 1 C.C. Gnd	ECU 23
Error Ignition coil 2 C.C. Vcc	ECU 24
Error Ignition coil 2 C.C. Gnd	ECU 25
Error Injector 1 C.C. Vcc.	ECU 26
Error Injector 1 C.C. Gnd	ECU 27
Error Injector 2 C.C. Vcc	ECU 30
Error Pump relay	ECU 36

Dashboard : DIAGNOSTICS



FAULTS ECU. The dashboard receives from the central computer only actual faults

Description	Error code
Error Local Loop-back	ECU 37
Error relay starter C.C. Vcc	ECU 44
Error relay starter C.C. ground	ECU 45
Error cannister C.C Vcc	ECU 46
Error cannister C.C. ground	ECU 47
Error battery high	ECU 50
Error ECU general	ECU 51
Error instrument panel	ECU 54
Error autoadaptation Tito I	ECU 55
Error vehicle speed	ECU 56
Error stepper C.A.	ECU 60
Error stepper C.C. Vcc	ECU 61
Error stepper C.C. Ground	ECU 62
Error unknown	ECU 00

Dashboard : DIAGNOSTICS



DASHBOARD ERRORS

In this mode a table lists eventual mistakes of the immobiliser and its connected sensors.

The error codes are explained as follows

Description	Error code
Immobiliser fault: key code read but not recognised	DSB 01
Immobiliser fault: key code not read (key not present or transponder broken)	DSB 02
Immobiliser fault: Antenna broken (open or short-circuit)	DSB 03
Immobiliser fault: internal controller fault	DSB 04
Fuel sensor fault	DSB 05
Air temperature sensor fault	DSB 06
Oil sensor fault	DSB 07
Oil pressure fault	DSB 08
The dashboard maintains memory of old errors.	

Dashboard : DIAGNOSTICS



CANCEL ERRORS

With this option only dashboard faults are erased. A final confirmation will be requested.

Reset service

This function allows to reset the service interval indicator. For the end of line testing purposes this operation also has the possibility for one time only to set the odometer to zero if done within the first 200 kilometers

DIAGNOSIS DSAHBOARD



Update

This function allows to reprogram the dashboard with new software via Axone.

On the display appears: *“dashboard disconnected”*.it is now possible to connect the *diagnostic tool* ; the dashboard will be reconnected normally after a key OFF/ON operation

Currently there is no new software

The white connector is underneath the saddle besides the fuse box close to the diagnostic connector of the injection system.

To connect Axone it is necessary to use the connector Ditech which is present at the confection of Axone 2000 Aprilia-Moto Guzzi





Function MODIFY KEYS

➔ This function can be used:

- 1) in case of key loss, the dealer can cancel the lost key
- 2) to activate up to 4 keys
- 3) if necessary use a new key ignition lock and memorise a new set of keys.

in the first phase it is requested to insert the user code and after giving confirmation that the key is memorised (1st key), it is requested to insert the other keys .

The procedure ends after four keys are memorised or after 20 seconds



Function CHANGE KEYS

- ➔ In case of the use of a new ignition key set, details of the procedure are as follows:
- ➔ Once turned the key to ON the dashboard not recognising the key will ask for the user code: insert the user code.
- ➔ At this point one can enter in MENU, DIAGNOSIS(inserting the service code) CHANGE KEYS and start the procedure of memorising the new keys.

Dashboard : DIAGNOSTICS




Indication of service interval

When nearing service interval mileage a small wrench will appear in the display. This will be at the same position as the ice symbol.

This indicator can be reset starting 300 kilometers prior to the service interval, in this 300 kilometer range the indicator will normally blink five seconds and then go off.

First time showing at 1500 kilometers, following activation every 10.000 kilometer



Dashboard : visualise warnings




The dashboard shows to the driver in the lower portion of its display the following alarms by keeping the red warning light on:

Oil level



Errors from computer or dashboard




SERVICE

Communication faults with the ECU



example:



Dashboard: DIAGNOSTICS



Engine oil sensor faults

The dashboard will reveal oil pressure faults as well as sensor faults. The oil sensor fault is detected with engine stopped and key in on position, if the sensor is not conducting (open circuit). This fault is indicated by lightening the warning “*service*” that will remain lit also with engine running

Abnormal oil pressure is indicated with engine running at an rpm higher than 2000 rpm and the sensor conducting (shorted). In this case the fault is indicated by lightening the icon “*oilcan*”.


In both cases codes are stored in the diagnostic memory of the dashboard

Dashboard : connections



PIN	SERVIZIO	PIN	SERVIZIO
1	+KEY	11	+BATTERY
2	COMAND RH INDICATOR	12	COMAND LH INDICATOR
3	OIL SENSOR	13	RESET INDICATOR/LED ANTTHEFT
4	BEAMLIGHTS IN	14	HAZARD
5	-	15	LED ANTI THEFT (if connected)
6	SELECT 1	16	SELECT 3
7	SELECT 2	17	SENSOR GROUND
8	FUEL LEVEL SENSOR	18	GENERAL GROUND
9	AIR TEMPERATURE SENSOR	19	GENERAL GROUND
10	-	20	GENERAL GROUND
PIN	SERVICE	PIN	SERVICE
21	+ BATTERY	31	-
22	+ BATTERY	32	-
23	ACTIVATE RELAY BEAMLIGHTS	33	-
24	-	34	ACTIVATION INDICATOR REAR.RH
25	COMMAND HANDLE HEATER	35	ACTIVATION INDICATOR FRONT.RH
26	CANL	36	ACTIVATION INDICATOR REAR.LH
27	CANH	37	ACTIVATION INDICATOR FRONT.LH
28	K-LINE	38	ACTIVATION HANDLE HEATER LH
29	-	39	ACTIVATION HANDLE HEATER RH
30	ANTENNA 1	40	ANTENNA 2

Engine



Engine: principle characteristics



Max output. KW 63,0 at 7500 rpm

Torque: Nm 85,0 at 6800 rpm

Idle speed: 1100 ± 100 giri/min

Intake valve lift: 10,74 mm

Exhaust valve lift: 10,74 mm

Gap (clearance) intake valve 0,15 ± 0,02 (inspect at 1000 km and every 10.000 km)

Gap (clearance) exhaust valve 0,2 ± 0,02 (inspect at 1000 km and every 10.000 km)

Generator with permanent magnet (alternator) with nominal power of 550 watt.

Engine: principle characteristics




From a technical point of view the engine is very similar to the one already installed to the V11.

A series of optimisations and improvements of single components have been Implemented.

Principal novelties are:

- **alternator** (is explained later in ELETTROMECHANICAL COMPONENTS)
- oil circuit with **pressure valve** and **external oil filter**
- **valve retainer with three grooves** to allow rotation for even wear of the valve →
- longer **drive shaft** (4 mm)
- new **1st piston ring** with L-shape to reduce blow-by gas
- **cylinder head and base gasket** metallic
- sintered **valve seats**
- **two spark plugs per cylinder** (is explained later in IGNITION COMPONENTS)
- new **aspect cylinder head covers**
- new **gearbox**



Engine: Lubrication group



The circuit is partially redesigned.

The **pressure valve** is now installed prior to the filter, in case of over pressure (valve opened), circulates the oil to the intake of the oil pump instead of release the oil to the crankcase, avoiding unwanted emulsing.

The **oil filter** is now accessible from the outside (exchange every 10.000 km like V11)

A **strainer** is introduced that improves the intake in any vehicle position and provides particles filtration

The oil level needs to be checked with the dipstick NOT fixed, different from V11, every 1000 km

Every 5000 km the drainage tube from the air filter housing needs to be emptied



Engine: Lubrication group




Recommended Engine Oil: Agip RACING 4T 5W-40

Recommended Gear box Oil : Agip ROTRA MP/S 85 W 140


Cardan Oil : TRUCK GEAR 85 W 140




Engine: Lubrication group



Engine: Lubrication group




Engine: Lubrication group



ESPLOSIONE WORK

Engine: oil filter



Oil filter

Engine: gearbox




6 speed gearbox with straight sliding gears and flexible coupling

The gears are mounted on roller bearings


The new pre-selector allows for a softer shift thanks to the desmodromic drum mounted on bearings

The flexible coupling contains an undulated washer that needs to dampen the vibrations at idle (noisy) while the 8 cup springs allow a gradual transmission of the engine torque as well in engagement as disengagement.

Engine: gearbox



Engine: gearbox




Engine: gearbox




Attention, the neutral switch needs to be removed before extracting the desmodromic drum when disassembling. In phase of reassembly it should be installed at the end of the procedure

Oil level is not checked based on a level measurement, but on the correct amount:
500 cc



Transmission gear



Transmission gear: principle characteristics




DESCRIZIONE	VALORI VALUES	DESCRIPTION
Riduzione coppia conica	3.667 / 1	<i>Bevel gear ratio</i>
Coppia continua alla ruota	530 Nm	<i>Continuous couple to the wheel</i>
Velocità max in entrata pignone	5650 rpm	<i>Input pinion max speed</i>
Peso a secco	10.37 Kg	<i>Dry weight</i>
Rotazione in entrata		<i>Input rotation</i>
SENSO ORARIO	●	<i>CLOCK WISE (C.W.)</i>
SENSO ANTIORARIO	○	<i>COUNTER CLOCK WISE (C.C.W.)</i>
Gioco di accoppiamento coppia conica	0.09+0.14 mm	<i>Bevel gear set backlash</i>
Precarico cuscinetti pignone conico (misurato sul D=44 mm senza anelli di tenuta)	25.9+28.6 daN	<i>Pinion bearings preloading (measured on D=44 mm without seals)</i>
Precarico totale cuscinetti corona-pignone (misurato sul D=44 mm senza anelli di tenuta)	32.7+36.3 daN	<i>Total pinion-ring gear bearing preloading (measured on D=44 mm without seals)</i>
Quantità olio richiesta	0.38 litri/litres	<i>Required oil capacity</i>
Specifica olio	AGIP ROTRA MP 80W 90	<i>Oil specification</i>

Pinion housing



Characteristics:
Check and change oil

**Oil filler and level
plug**



**Oil bleeder
plug**

Oil drain plug

Pinion housing : oil




Operazione <i>Operation</i>	Primo Intervento <i>First time</i>	Manutenzione ordinaria <i>Ordinary maintenance</i>
Cambio olio <i>Oil change</i>	1000 Km <i>1000 Km</i>	stagionale od ogni 20000 Km <i>seasonally or every 20000 Km</i>
Pulizia tappo magnetico olio <i>Clean magnetic oil plug</i>	primo cambio d'olio <i>first oil change</i>	ogni cambio d'olio <i>every oil change</i>
Controllo e rabbocco olio <i>Check and adjust oil level</i>	1000 Km <i>1000 Km</i>	mensile od ogni 5000 Km <i>mensile or every 5000 Km</i>


Transmission gear: disassembly and assembly



The assembly/disassembly operations are related to the replacement of the rubber covers 6 and 14 and the washer 10.



Transmission gear: disassembly and assembly





Transmission gear: disassembly and assembly



Relative to the rotating axle are replaceable only the 2 bearings with universal pullers.


Reassembly is effected heating both bearings to 100° C



Transmission gear: disassembly and assembly




For the pignon group we can only replace the sealer with its respective holder



Transmission gear: disassembly and assembly



The support group is completely replaceable.



Transmission gear: special tools



Support housing

Tampone tenuta asse ruota



Manico

Tampone snodo sferico


Spanner sealer pignon

Tampone tenuta ghiera pignone

Support transmission gear



Electronic injection



Electronic injection 5AM 2



DESCRIPTION INJECTION-IGNITION SYSTEM

General information on injection-ignition system

The injection and ignition system with electronic integrated control allow to optimize performance and operation of the engine, reducing the specific consumption and polluting elements in the exhaust gas.

With these systems, as a matter of fact, is guaranteed an optimal report between air and fuel and ignition timing advance management

Electronic injection



Effect of the relation air to fuel and ignition timing advance

- **The correct management of the relation between air and fuel and the ignition timing advance is the basis of the optimal functioning of the engine. The ideal relation between air and fuel is the stochiometric relation in weight, which determines the complete combustion**

insufficient air or air in access will create a rich or lean mixture, which will influence output and consumption as well as emissions in the exhaust. The electronic ignition advanced control allows to optimize the performance of the engine, create maximum output, reduce fuel consumption and polluting elements in the exhaust gas.

The electronic ignition advanced control integrated with the injection control, allows to realize the best functioning of the engine in all conditions of its use (starting at low-temperature, phase of warming up, transitional phase of acceleration and deceleration, engine in conditions of partial load, full load and idle speed)

Electronic injection 5AM 2



Actuator control is determined by the information received from the sensors:

- amount of fuel injected to each cylinder in sequential mode and not parallel, by controlling the opening time of the injectors and thus also injection timing is referred to the intake stroke of each cylinder
- ignition timing advance (ignition coil)

Principal novelty on the system of injection with computer Marelli 5AM 2I lies in the control of **idle speed** that is affected by a stepper motor that allows air to enter in the combustion chamber by-passing the throttle valve.

Its position is modified by the computer to maintain idle speed stabilized, in function of environmental conditions (engine temperature, air temperature,...)

Electronic injection : fuel circuit



Fuel tank: capacity | 23 ± 0,5 l

The fuel pump group that is positioned in the fuel tank contains:

- fuel level indicator sensor
- fuel filter
- fuel pressure regulator
nominal pressure value 3bar
- power supply 12V



Electronic injection : fuel circuit



Injectors

The command sent by the computer is of the pulsating type. This will determine the movement of the center part of the solenoid, revealing the opening of the injector

With a constant fuel pressure determined by the regulator, present on the pump, of $3 \pm 0,2$ bar, the quantity injected depends exclusively of the opening time of the injector

Power supply 12V

Resistance $14 \Omega \pm 2$ at 20°C



Electronic injection : fuel circuit



Pay attention to the position of the fuel tube from fuel tank to injectors that needs to run aside the air filter not underneath



Electronic injection : intake air



- **Air temperature sensor** NTC installed in air filter housing



°C	kohm
-40	100.950
-0	9.750
+10	5.970
+20	3.750
+30	2.420
+40	1.600
+90	0.280

Electronic injection : intake air



Potentiometer throttle valve

This sensor informs the computer about the position of the throttle valve. The mechanical degrees are transferred into an electrical signal under the form of voltage. In function of this signal the computer foresees to adjust the time of injection to optimize the stochiometric report.

Connector with three wires:

Power supply 5V

Ground provided by computer

Valve position signal, scale:

**Appr. from 0,55 (at stopper) to
4,4 V(max. opening)**




Electronic injection :computer 5AM 2



Located in front underneath the fuel tank has to connectors




Connector A - from 1 to 38 pin



Colore Nero

Connector B - from 1 to 38 pin




Colore Grigio

Electronic injection :computer 5AM 2



Connections Engine Computer

Connector A



* Not connected


- | | |
|------------------------------|----------------------------------|
| 1* | 20 power supply 5V (sensors NTC) |
| 2* | 21* |
| 3 TPS signal | 22* |
| 4* | 23 neutral signal |
| 5 Engine temperature sensor | 24* |
| 6* | 25 RPM sensor signal |
| 7* | 26* |
| 8* | 27* |
| 9 stepper motor + | 28 Injector cylinder lh. |
| 10 command ignition coil rh. | 29 Power-supply TPS sensor. |
| 11* | 30* |
| 12* | 31* |
| 13* | 32 ground TPS sensor. |
| 14 air temperature signal | 33* |
| 15* | 34 shield wire RPM sensor |
| 16* | 35 RPM sensor signal |
| 17 stepper motor + | 36* |
| 18 stepper motor - | 37 injector cylinder rh |
| 19 stepper motor - | 38 ignition coil lh. |

Electronic injection :computer 5AM 2



Connections Engine Computer

Connector B



* Not connected

- | | |
|--|---------------------------------|
| 1 start relay command pin 85 | 20 CAN – H (ccm/dashboard) |
| 2* | 21* |
| 3* | 22 oxygen sensor signal |
| 4 protected power-supply from dash board | 23* |
| 5* | 24 speed sensor signal in |
| 6 secondary relay command pin 86 | 25* |
| 7 k-line (reprogramming dashboard) | 26* |
| 8* | 27 “engine kill” in |
| 9* | 28 start signal in |
| 10* | 29 CAN – L (ccm/dashboard) |
| 11 negative command oxygen sensor | 30* |
| 12* | 31* |
| 13* | 32 power supply oxygen sensor |
| 14* | 33 clutch sensor signal |
| 15* | 34* |
| 16 K- line (diagnosis) | 35 fall down sensor signal |
| 17 power-supply main relay | 36* |
| 18* | 37* |
| 19* | 38 lateral stand sensor signal. |

COMPONENTS –IGNITION




The system used is of the inductive type.
The computer works with following parameters:

- Engine load,
- Engine temperature,
- Injection time: determines the command of ignition advance

Primary: to measure
between pin 1 and 15.
value:

0,9 a 1,1 Ω



Secondary: to measure at the high
tension exits.

value:

6,5 a 7,2 K Ω





COMPONENTS –IGNITION



Spark plug cap and spark plug

Engine equipped with double ignition

Production make
NGK
position 1 PMR8B
position 2 BPR6ES
Cap resistances 5 k Ω



To avoid fast wear of the platinum electrodes
of the internal plug, it is important not to switch
The high tension cables on the bobine

(cable with red marking – external plug)



COMPONENTS – ELECTRICS



Speed sensor

Located at front fork:
inductive active type

Connector with 3 pin:

- Power-supply 12V
- Outgoing signal from pin 24 connector B
- ground



Resistance:
With connector disconnected
between pin 2 e 3
from 500 to 600 Ω circa



COMPONENTS – ELECTRICS



Engine temperature sensor

This sensor is supplied with 5V has NTC characteristic, sends to the computer a variable signal in function of the temperature, to manage stoichiometric report during engine warm-up



°C	KΩ	°C	KΩ
- 40	100.950	+40	1.600
- 30	53.100	+50	1.080
- 20	29.120	+60	0.750
- 10	16.600	+70	0.530
0	9.700	+80	0.380
+10	5.970	+90	0.280
+20	3.750	+100	0.204
+30	2.420	+110	0.153
		+125	0.102

COMPONENTS – ELECTRICS



Crankshaft position sensor

RPM and alignment sensor, measures engine RPM and position of each cylinder with respect to TDC. A sensor with connector with three wires.:

pin positive tension

pin negative tension

pin shield wire

Resistance value **650 to 720 Ω circa**

Air Gap:

Measures sensor length with Calliper:

From 0,6 mm to 0,7mm



COMPONENTS – ELECTRICS



Idle speed control

The computer in order to increase the amount of by-pass air, with in consequence the increase of engine rpm at idle, uses a stepper motor.

Its function consists of a displacement of the central axis which by its rotational movement opens and closes the bypass, thus allowing air to by-pass the throttle valve.


The parameters used to vary the passage, coming from various sensors are:

- Engine RPM
- Coolant temperature

If the engine is warmed-up, the stepper motor operates in CLOSED LOOP to obtain target speed set by the computer

Impulse Commands

Resistance value:
between 1 and 4 = 50Ω
between 2 and 3 = 50Ω




COMPONENTS – ELECTRICS



Emission control

To obtain an ideal mixture it is necessary that the amount of intake air for the combustion is in equal measure to the theoretical amount needed for a complete combustion of the fuel injected in the intake manifold

- $\lambda >$ lean mixture
- $\lambda <$ rich mixture
- $\lambda =$ optimal



- a. Rich mixture (lack of air)
- b. Lean mixture (too much air)



COMPONENTS – ELECTRICS




Lambda Sensor


In contact with exhaust gas, the oxygen sensor generates an electrical signal of which the value represents the amount of oxygen present in the exhaust gas itself.

Because the sensor needs to reach a temperature of about 350°C to function correctly, in order to avoid thermal shock at cold engine condition, the computer foresees in sensor heating. Sensor and heater are integrated in a ceramic element thus obtaining fast heating. In this way in very short period of time is obtained the control in so-called closed loop (lambda control) which stoichiometric report

- 1 ceramic coating
- 2 protection element
- 3 sensor body
- 4 ceramic support
- 5 plane sensor
- 6 protection
- 7 electric wire



Schematic of sensor



- 1- exhaust gas
- 2 – reference air
- 3 - heater
- 4 –reference tension


COMPONENTS – ELECTRICS




Three-way catalytic converter

This component is used to reduce three principal polluting elements:

- Carbon Monoxide = CO
- Raw hydrocarbons = HC
- Nitrogen oxides = NO_x



the internal construction consists of a metallic support in which is deposited a substrate of a chemical material that under operating temperature initialise a catalytic process, transforming CO in CO₂, HC and NO_x in water vapour and N₂.



COMPONENTS – ELECTROMECHANICS



Relays (under the seat)

- A = Secondary injection relay
- B = Lights relay
- C = Start relay
- D = Main injection relay

Battery (under the seat)

YTX 20 CH-BS 18A/h
Maintenance Free




COMPONENTS – ELECTROMECHANICS




Engine oil pressure sensor

This sensor per default is shorted to ground. With the engine running the pressure existing in the lubrication system will interrupt the contact, signaled by pin 3 of the gray connector in the dashboard



Neutral sensor

Also this sensor per default is shorted to ground. Every time the vehicle is shifted into gear the contact remains open signaling to the computer via pin 23 of black connector (A)



COMPONENTS – ELECTROMECHANICS



Starter motor

The activation of this actuator is realized by a solenoid commanded by the computer:

- Key ON
- Security switches line in continuity
- Start switch on

This command remains present in the computer for 10 seconds; only when 400 engine rpm are achieved the signal is automatically deactivated.

characteristics:
12V



COMPONENTS – ELECTROMECHANICS



Alternator



characteristics:

12V nominal

Max load 40A (550W)



Initial load > 1110 rpm

Regulator 14,2 to 14,8V

5000 rpm 10A- 25°C

Range Temp. – 30 a 90°

Belt replacement every
50.000 km




Belt tensioner



Procedure for the alternator belt tensioning

To set the correct tensioning of the belt it is necessary to use the specific tool: “belt tensioner tool”. and torque wrench

- Fix the fulcrum screws of the alternator (M10) at approximately 10 Nm
- Put tension to the belt according to the value described in the workshop manual (different between belt installed for first-time or already installed at least one time) and lock the alternator with the locking screws
- Fix the securities bolts and the relative nut
- Fix with the correct torque the fulcrum screws and the locking screws



Security systems



The security system exists of the following components:

- Fall sensor
- Clutch sensor
- Neutral sensor
- Stand sensor

All of these sensors are directly connected to the computer which in function of the signals received from these components allow the functioning of the engine and its start-up

Fall sensor

This sensor correctly positioned and with the engine running is in open contact. In case the vehicle falls over, the sensor closes its contact to ground via pin 35 of connector B.

The computer sensing this dangerous situation stalls the engine

If the vehicle is turned upright again, one needs to wait 10 seconds after turning key to off before turning back to on to allow starting, (activating the power latch)

Security systems




LOGIC LATERAL STAND/CLUTCH FOR BREVA 1100 01.03.04

GEAR	STAND	CLUTCH	ENGINE	STARTING	STAND WARNLIGHT
NEUTRAL	UP	ENGAGED	FUNCTIONS	POSSIBLE	OFF
		DISENGAGED			
	DOWN	ENGAGED			ON
		DISENGAGED			
GEAR	UP	ENGAGED	DOES NOT FUNCTION	NOT POSSIBLE	OFF
		DISENGAGED			
	DOWN	ENGAGED			ON
		DISENGAGED			

GEAR: Neutral position means contact closed. In gear means contact opened

STAND: Raised means contact closed, lowered means contact open

CLUTCH : Engaged means contact closed, disengaged contact open



ENGINE DIAGNOSIS



Diagnostic connector

Besides the possibility to effectuate the diagnosis of the engine ECU via the dashboard in position “diagnostics” faults ACT, the diagnostic connector is available under the seat next to the fuse box. This connection allows to control with Axone in section parameters eventual reprogramming of the computer (currently not foreseen) and activate some components of the injection system, visualise faults both ACT and MEM



AXONE





Software Axone:

The new software 5.0.4 for Axone will permit the connection to the ECU

Select AUTODIAGNOSI, BREVA, 1100, and confirm following the Axone instruction showed on the screen.


Throttle valve zero position learning procedure

Is performed in following circumstances:

- Throttle valve body and or sensor replacement,
- Computer replacement or cylinder balancing


Select in the screen

ADJUSTING PARAMETERS



The parameter **LEARNING THROTTLE POSITION SENSOR**

- How do we verify correct implementation? In the screen parameters engine



I should see : throttle position $4,7 \pm 0,2$ °



Recovery function

In case any of the following sensor signals is disturbed the computer continues operation with replacement values.

Dashboard and Axone in any case are showing the malfunction.

Air temperature:	25 °C
Engine temperature:	30 °C , with linear increase parallel to air temp.
Barometric pressure:	1010 hPa
Throttle position sensor:	2,9 ° at minimum, otherwise variable
Stepper motor:	Fixed value



Sonda Lambda:

To verify if the computer uses the lambda sensor feedback signal can be seen in Screen Components status



The parameter **STATUS LAMBDA:** should indicate **CLOSED**.

This condition can be verified at idle, only when all following conditions are met :

Air temperature above 18 °C

Engine temperature above 18 °C

Engine has operated for approximately 2-3 minutes

AXONE: active screens




ISO screen:



- **MAP** Visualise actual mapping present in computer

Engine parameter screen:



Visualise the usual engine parameters. New are the parameters for the stepper motor

- **STEPPER C.L.** indicates the step number set by the computer
- **EQUIVALENCE OF STEPPER** if not at idle, indicates air contribution by the stepper motor in degrees of throttle opening

AXONE: active screens



Component status screen:



It is possible to visualise the component status for the security components and other systems, like the lambda sensor and rpm sensor

- **FALL SENSOR:** If vehicle is fallen over it shows TIP OVER
- **SWITCH RUN/STOP:** I can see in which status the switch is
- **IGNITION:** indicates if the computer based on the status of the security components and immobiliser will allow for engine starting

AXONE: active screens



Screen component activation:



- From this screen I can activate a series of components
- The CANCEL ERRORS will only delete errors from the engine computer memory

Screen error visualisation:



For the majority of detected errors, once selected the error and pressing the enter button on Axone, one will see a detailed description of the error.


THROTTLE BALANCING



Procedure of adjustment and controlling throttle bodies

Connect Axone to the diagnostic connector of the vehicle and to its battery and follow the indications given by Axone

- Connect the vacuum meter to the two intake collectors
- Connect Axone and follow indications
- Put the key to ON
- Make sure there are no faults present in the computer. In case there are, resolve them and restart the procedure



THROTTLE ALIGNMENT



- Assure that the LH throttle is resting at the stopper

Note:

Don't move absolutely the throttle stopper, to avoid the need of throttle body replacement.



Throttle stopper

- Select the parameter "Self learning of the throttle" in the screen Regulating Parameters
- Turn the key to OFF for 30s
- Turn the key to ON to reestablish the connection with Axone
- Check that the value indicated "Throttle" is 4,5 – 4,9 °. In case the value is not correct replace the engine computer and repeat the procedure from the beginning.




THROTTLE ALIGNMENT



- Completely close the by-pass screws
 - Start the engine and warm up to 60°
Run the engine at 2000/3000 rpm and with the vacuum meter, check if there is a correct difference of vacuum between the two cylinders of maximum 1 cm Hg (1,33 kPa).
If this is the case continue at point 1
If difference is higher proceed at point 2
1. Run the engine at idle and check that the vacuum between the two cylinders is balanced.
If this is not the case open **ONLY** the bypass screw of the cylinder with the highest underpressure to obtain equal values between left and right



Bypass LH



Bypass RH

ALLINEAMENTO FARFALLE



2. Adjust the adjuster on the throttle bodies connecting rod to reduce the vacuum difference between left and right.



- ➔ Apply again the procedure for “**Autolearning throttle position**” as explained before
- ➔ Run the engine at idle and check the vacuum difference between left and right. If difference exists open **ONLY** the by-pass screw on the side with the higher underpressure to obtain correct balance.

SPECIAL TOOLS: new



preliminary list

	codice	nome attrezzo	note
1	05,94,86,30	belt tensioner tool	
2	05,91,17,30	front cover insertion cone	oil return ring protection cone on cover
3	05,91,26,30	dismantling clutch tool	4 teeth, d.38 mm. Also usable for damper adjustment: equal to RSV 1000 code 8140191
4	05,91,25,30	gearbox opener	
5	05,90,19,30	internal sparkplug spanner	allows removal with filter installed
6	05,92,80,30	piston ring compressor	d.interno cilindro=92 mm
7	05,92,72,30	distribution cover washer	punzone


SPECIAL TOOLS: existing



	codice	nome attrezzo	note
8	30949700	Attrezzino rimozione anelli forcella	verificare se va bene questo del V11
9		ghiera sterzo	va bene quello dell'RSV 1000 D.48 mm codice 8140190
10	01 92 91 00	Chiave per smontaggio coperchietto sulla coppa e filtro	attrezzo effettuato per V11
11	14 92 96 00	Supporto per scatola cambio	attrezzo effettuato per V11
12	19 92 96 00	Disco graduato per controllo messa in fase distribuzione e accensione	attrezzo effettuato per V11
13	17 94 75 60	Freccia per controllo messa in fase distribuzione e accensione	attrezzo effettuato per V11
14	12 91 36 00	Atrezzo per smontaggio flangia lato volano	attrezzo effettuato per V11
15	12 91 18 01	Atrezzo per bloccare il volano e la corona avviamento	attrezzo effettuato per V11
16	10 90 72 00	Atrezzo per smontaggio e montaggio valvole	attrezzo effettuato per V11
17	30 91 28 10	Atrezzo per bloccaggio corpo intero frizione	attrezzo effettuato per V11
18	30 90 65 10	Atrezzo per montaggio frizione	attrezzo effettuato per V11
19	14 92 71 00	Atrezzo per montare l'anello di tenuta sulla flangia lato volano	attrezzo effettuato per V11
20	12 91 20 00	Atrezzo per montaggio flangia lato volano completa di anello di tenuta sull'albero motore	attrezzo effettuato per V11
21	19 92 71 00	Atrezzo montaggio anello di tenuta sulla flangia lato volano	attrezzo effettuato per V11
22	14 92 73 00	Atrezzo per tenuta ingranaggio albero a camme	attrezzo effettuato per V11
23	65 92 84 00	Mozzo per disco graduato	attrezzo effettuato per V11

**preliminary
list**

EWD : DASHBOARD




Legenda:

- | | | | |
|------------------------|------------------------------|--------------------------|--------------------------------|
| 1)Front indicator RH | 8)Oil pressure warning light | 15) Immobilizer antenna | 22) Stop switch RH |
| 2)Front position light | 9)Fuel level sensor | 16) Diagnostic connector | 23) Ambient air temperature |
| 3)Beam headlight | 10)Light relay | 17) Heated handle RH | 24) Rear indicator RH |
| 4)Headlight | 11)Horn | 18) Heated handle LH | 25) Stop light |
| 5)Front indicator LH | 12)Light switches LH | 19) Handle heater switch | 26) Rear indicator LH |
| 6)Alternator | 13)Light switches RH | 20) Hazard switch | 27) License plate illumination |
| 7)Starter relay | 14)CAN line | 21) Stop switch LH | 28) Ignition switch |

EWD : ALTERNATOR




Wiring diagram alternator



EWD: SECURITY SYSTEM



BREVA 1100 Security logic



Legenda

- | | |
|-------------------------|---------------------------|
| 2 Clutch switch | 31 Oil pressure warning |
| 3 Starter relay | 32 Neutral Gear switch in |
| 5 Light switch RH | 34 Lateral stand sensor |
| 29 Main injection relay | 50 Tip-over sensor |
| 25 Starter motor | |

EWD: ENGINE ECU

