



- KEY**
- MULTIPLE CONNECTORS
 - CLUTCH SWITCH
 - START-UP RELAY
 - START-UP MAINTENANCE RELAY
 - LIGHT LOGIC RELAY
 - FOG LIGHTS RELAY (OPTIONAL)
 - RIGHT LIGHT SWITCH
 - LEFT LIGHT SWITCH
 - HORN
 - AMBIENT AIR TEMPERATURE SENSOR
 - INSTRUMENT PANEL
 - IMMOBILIZER AERIAL
 - KEY SWITCH
 - HEATED HANDGRIPS
 - GPS COUPLING
 - GLOVE-BOX OPENING RELAY
 - ELECTRIC LOCK
 - REAR RIGHT TURN INDICATOR
 - REAR LIGHT ASSEMBLY
 - REAR LEFT TURN INDICATOR
 - LICENSE PLATE LIGHT BULB
 - REAR STOP SWITCH
 - FRONT STOP SWITCH
 - ABS CONTROL UNIT
 - FRONT WHEEL SPEED SENSOR
 - REAR WHEEL SPEED SENSOR
 - ANTITHEFT DEVICE ECU (OPTIONAL)
 - HELMET COMPARTMENT SWITCH
 - AUXILIARY FUSES
 - STARTER MOTOR
 - MAIN FUSES 2
 - MAIN FUSES 1
 - BATTERY
 - POWER SUPPLY SOCKET
 - GENERATOR
 - GENERATOR
 - MAIN INJECTION RELAY
 - SECONDARY INJECTION RELAY
 - OIL PRESSURE SENSOR
 - NEUTRAL SENSOR
 - LAMBDA PROBE
 - SIDE STAND SWITCH
 - FUEL RESERVE SENSOR
 - FUEL PUMP
 - INTAKE AIR TEMPERATURE SENSOR
 - ENGINE TEMPERATURE SENSOR
 - IDLE MOTOR
 - THROTTLE POSITION SENSOR
 - RIGHT CYLINDER COIL
 - LEFT CYLINDER COIL
 - RIGHT CYLINDER
 - LEFT CYLINDER
 - RIGHT CYLINDER INJECTOR
 - LEFT CYLINDER INJECTOR
 - FALL SENSOR
 - PICK UP
 - ECU
 - FOG LIGHTS (OPTIONAL)
 - FRONT LEFT TURN INDICATOR
 - TAIL LIGHT BULB
 - LOW-BEAM/HIGH-BEAM BULB
 - FRONT RIGHT TURN INDICATOR
 - INSTRUMENT PANEL DIAGNOSIS
 - ECU DIAGNOSIS
 - HIGH-BEAM LIGHT RELAY

- COLOUR KEY**
- Ar Orange
 - Az Sky blue
 - B Blue
 - Bl White
 - G Yellow
 - Gr Grey
 - M Brown
 - N Black
 - R Red
 - Ro Pink
 - V Green
 - Vi Purple

- DIAGRAM COLOURS - KEY**
- POWER SUPPLY
 - GROUND
 - ENABLING / SIGNAL
 - ENABLING / SIGNAL

- ECU CONNECTORS KEY**
- E Brown
 - V Blue

