



- 1. Speedometer 3W
- 2. Auxiliary light 5W
- 3. High beam indicator 1.2W
- 4. Oil pressure indicator 1.2W
- 5. Neutral indicator 1.2W
- 6. Headlights indicator 1.2W
- 7. Generator indicator 1.2W
- 8. Headlight low beam 40W
- 9. Headlight high beam 45W
- 10. R/H front turn signal 21W
- 11. L/H front turn signal 21W
- 12. Engine kill switch
- 13. Additional switch
- 14. Control switch: turn signals, lights and horn
- 15. Horns (7A)
- 16. Front brake switch
- 17. High beam flash relay
- 18. Rear brake switch
- 19. Battery
- 20. Regulator
- 21. Rectifier
- 22. Alternator
- 23. Starter relay
- 24. Starter motor
- 25. Neutral switch
- 26. L/H rear turn signal
- 27. Taillight and stop light 5W/21W
- 28. License plate light 5W/5W
- 29. R/H rear turn signal
- 30. Turn signal flasher
- 31. Oil pressure switch
- 32. Parking light 4W
- 33. Fuse holder (16A fuses)
- 34. Connector 3-way
- 35. Connector, AMP 2-way
- 36. Points
- 37. Ignition coils
- 38. Ignition switch (3 position)
- 39. Connector, AMP 2-way
- 40. Connector
- 41. Spark plugs
- 42. Parking light