





Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.	
1	Battery 12V-24Ah	-	-	-	F	-	GU28704552	1	
2	Float chamber	-	-	-	-	-	GU14707000	1	
3	Accumulator fixing wedge	-	-	-	-	-	GU14705350	1	
4	Clamp	-	-	-	-	-	GU19704800	1	
5	Spacer	-	-	-	-	-	GU91180605	2	
7	HT coil	-	-	-	-	-	GU31716560	2	
8	Screw	-	-	-	-	-	GU98620240	4	
9	Spacer	-	-	-	-	-	GU91180721	4	
10	Ring nut	-	-	-	-	-	GU19741336	1	
11	Bosch rectifier	-	-	-	-	-	GU17704300	1	
12	Cover	-	-	-	-	-	GU61704200	1	
13	Ground-battery lead	-	-	-	-	-	GU19748400	1	
14	Washer 6,4x12x1,2	-	-	-	-	-	GU95100141	2	
15	Nut M8X1,25	-	-	-	-	-	GU92602208	1	
16	Spring washer 5,3X10X0,5	-	-	-	-	-	GU95129100	6	
17	Nut	-	-	-	-	-	GU92602205	4	
18	Voltage regulator BOSCH	-	-	-	-	-	GU29703800	1	
19	Washer	-	-	-	-	-	GU95004208	2	
21	Screw	-	-	-	-	-	GU98054214	2	
22	Lock hardware kit	-	-	-	-	-	GU27736885	1	
23	Main switch	-	-	-	-	-	GU31735360	1	
24	Screw	-	-	-	-	-	GU98290512	2	
25	Washer	-	-	-	-	-	GU95000205	2	
26	Phase/revolution sensor	-	-	-	-	-	GU29722270	1	
27	Hex socket screw M6X18	-	-	-	-	-	GU98622318	1	
29	Pick-up rotor	-	-	-	M1	-	GU27721036	1	
	Rotor	-	-	-	M2	-	GU27721063	1	
30	Notched washer	-	-	-	-	-	GU95021105	3	
31	Repairing kit	-	-	-	-	-	GU17719900	1	
32	Screw	-	-	-	-	-	GU14712459	1	
33	Rubber spacer	-	-	-	-	-	GU19007700	1	
34	Wire	-	-	-	-	-	GU19748000	1	
35	Cap	-	-	-	-	-	GU19707100	2	

36	Hose clamp 3,6x20,6	-	-	-	-	-	GU14609650	20
37	Hex socket screw M5X45	-	-	-	-	-	GU98620245	3
38	Hex screw M8X35	-	-	-	-	-	GU98052435	2
39	Sparkplug cap	-	-	-	-	-	GU14717400	2
40	Spark plug NGK B8ES	-	-	-	-	-	GU31717060	2
	Spark plug MARELLI CW8LP	-	-	-	-	-	GU17917001	2
	Spark plug MARELLI F8LCR	-	-	-	-	-	GU19717007	2
41	Bosch alternator	-	-	-	-	-	GU17712400	1
42	Protection	-	-	-	B	-	GU19733350	1
43	Starter motor	-	-	-	L	-	GU19700720	1
	Starter motor Valeo	-	-	-	V	-	GU30730711	1
44	Starter motor revision kit	-	-	-	B	-	GU14730570	1
	Starter motor revision kit	-	-	-	L	-	GU19730580	1
45	Generator SAPRISA	-	-	-	S	-	GU28712400	1
46	Screw	-	-	-	S	-	GU98620250	3
47	Screw	-	-	-	S	-	GU28712459	1
48	Voltage regulator SAPRISA	-	-	-	S	-	GU28703800	1
49	Connector SAPRISA	-	-	-	S	-	GU28712500	1
50	Screw	-	-	-	S	-	GU98202520	3
51	Washer	-	-	-	S	-	GU95000205	4
52	Nut	-	-	-	S	-	GU92630105	2




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Front mudguard	-	-	-	-	gy	GU27434336	1
	Front mudguard	-	-	-	-	b	GU27434337	1
	Front mudguard	-	-	-	-	gr	GU27434420	1
	Front mudguard	-	-	-	-	r	GU27434321	1
2	Screw	-	-	-	-	-	GU98230816	4
3	Splash guard	-	-	-	-	-	GU27436920	1
4	Eyelet	-	-	-	-	-	GU28659740	2
5	Splash guard	-	-	-	-	-	GU27438635	1
6	Hex screw M6X20	-	-	-	-	-	GU98054320	6
7	Rubber spacer	-	-	-	-	-	GU93110060	8
8	Washer	-	-	-	-	-	GU95000206	4
9	Washer 6,4x12x1,2	-	-	-	-	-	GU95100141	4
10	Nut M6x1	-	-	-	-	-	GU92630106	4
11	Drift	-	-	-	-	-	GU19705900	2
12	Rear mudguard	-	-	-	-	-	GU27437085	1
13	Washer 6,15x11x0,8	-	-	-	-	-	GU95004206	1
14	Rubber spacer	-	-	-	-	-	GU93110082	2
15	Nut M6x1	-	-	-	-	-	GU92630106	2
16	Rear headlight supp.	-	-	-	-	-	GU27474385	1
17	Rubber spacer	-	-	-	-	-	GU91551085	2
18	Spacer	-	-	-	-	-	GU91180607	2
19	Nut M6x1	-	-	-	-	-	GU92630106	2
20	Rear fairing	-	-	-	-	gy	GU27472635	1
	Rear fairing	-	-	-	-	b-r	GU27472688	1
	Rear fairing	-	-	-	-	gy-r	GU27472687	1
	Rear fairing	-	-	-	-	gy-r	GU27472686	1
	Rear fairing	-	-	-	-	r	GU27472636	1
	Rear fairing	-	-	-	-	gr	GU27472685	1
21	Screw	-	-	-	-	-	GU98290516	2
22	Washer 6,15x11x0,8	-	-	-	-	-	GU95004206	1
23	Covers assy	-	-	-	-	-	GU27462085	1
24	Nut	-	-	-	-	-	GU92602205	2
25	Washer	-	-	-	-	-	GU95000205	2

26	Captive nut	-	-	-	-	-	GU92660501	2
27	Rubber spacer	-	-	-	-	-	GU91551082	2
28	Lock	-	-	-	-	-	GU27468720	1
29	Special cap screw M5x10	-	-	-	-	-	GU98290511	2
30	Nut	-	-	-	-	-	GU92602205	2
31	Grommet	-	-	-	-	-	GU91551092	1
32	Fairing	-	-	-	DA	gy-r	GU27585387	1
	Windshield	-	-	-	-	b-r	GU27575488	1
	Fairing	-	-	-	DR	gy-r	GU27575386	1
	Fairing	-	-	-	-	gy-n	GU27575335	1
	Fairing	-	-	-	-	gy-r	GU27575336	1
33	Windshield	-	-	-	DR	gy-r	GU27575486	1
	Windshield	-	-	-	-	gr	GU28575410	1
	Windshield	-	-	-	DA	gy-r	GU27575487	1
	Windshield	-	-	-	-	gy-n	GU27575435	1
	Windshield	-	-	-	-	b-r	GU27575488	1
	Windshield	-	-	-	-	gy-r	GU27575436	1
34	Windscreen	-	-	-	-	-	GU28577210	1
35	Screw	-	-	-	-	-	GU28576010	2
36	"MotoGuzzi" dec.	-	-	-	-	-	GU28923400	1
37	Number plate holder	-	-	-	-	-	GU14474650	1
38	Screw	-	-	-	-	-	GU98052220	4
39	Spacer	-	-	-	-	-	GU90716057	8
40	Washer 5,25x14x1,5	-	-	-	-	-	GU95100059	8
41	Nut	-	-	-	-	-	GU92630105	4
42	Washer	-	-	-	-	-	GU95007204	2
43	Nut	-	-	-	-	-	GU92781040	2
44	Operator's handbook	-	-	I	-	-	GU27900035	1
45	O-ring	-	-	-	-	-	GU90706092	8
46	Bush	-	-	-	-	-	GU28436460	4




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Fuel tank	-	-	-	DO gy	GU27100235	1	
	Fuel tank	-	-	-	DB r	GU27100236	1	
	Fuel tank	-	-	-	DR gy	GU27100286	1	
	Fuel tank	-	-	-	DA r	GU27100287	1	
	Fuel tank	-	-	-	- b	GU27100288	1	
	Fuel tank	-	-	-	- gr	GU231002301	1	
2	Tank cap	-	-	-	-	GU62103920	1	
4	"Moto Guzzi" dataplate	-	-	-	-	GU28917300	2	
5	Indicator fuel level	-	-	-	-	GU27103085	1	
	Plug	-	-	-	T1	GU28105280	1	
	Fuel level sensor	-	-	-	-	GU29103050	1	
6	Rubber pipe 12,5X7,8 5/16"	-	-	-	-	GU00823956080	1	
7	Rubber pipe 12,5X7,8 5/16"	-	-	-	-	GU00823956080	1	
8	Connecting	-	-	-	-	GU27106385	1	
9	Screw	-	-	-	-	GU98622312	1	
10	Washer 6,2X18X1	-	-	-	-	GU95100118	2	
11	Nut	-	-	-	-	GU92602206	1	
12	RH fuel cock	-	-	-	T1	GU23105140	1	
	LH fuel cock	-	-	-	T1	GU23105370	1	
	Vacuum fuel tap	-	-	-	-	GU27105385	1	
13	Rubber pipe 12,5X7,8 5/16"	-	-	-	-	GU00823956080	1	
14	Rubber pipe 12,5X7,8 5/16"	-	-	-	-	GU00823956080	1	
15	Breather pipe	-	-	-	-	GU00823946060	1	
16	Rubber pipe 12,5X7,8 5/16"	-	-	-	-	GU00823956080	2	
17	Cock	-	-	-	-	GU27105485	2	
18	Tie rod	-	-	-	-	GU19102750	1	
19	Hose clamp	-	-	-	-	GU28108410	12	
20	Saddle	-	-	-	-	GU27460586	1	
21	RH body panel blank	-	-	-	- gr	GU194762501	1	
	RH side panel	-	-	-	DA r	GU21570337	1	
	RH side panel	-	-	-	DO gy	GU27570333	1	
	RH side panel	-	-	-	DB r	GU27570334	1	
	RH side panel	-	-	-	DR gy	GU27570336	1	
	RH side panel	-	-	-	- b	GU27570338	1	

22	LH side panel	-	-	-	DO	gy	GU27570433	1
	LH side panel	-	-	-	-	b	GU27570438	1
	LH side panel	-	-	-	DA	r	GU27570437	1
	LH side panel	-	-	-	DB	r	GU27570434	1
	LH body panel blank	-	-	-	-	gr	GU194763501	1
	LH side panel	-	-	-	DR	gy	GU27570436	1
23	"V35" finish	-	-	-	-	-	GU19922000	2
24	"III" mark	-	-	-	-	-	GU27922036	2
25	Decal set	-	-	-	DO	-	GU27923335	1
	Decal set	-	-	-	DB	-	GU27923385	1
	Decal set	-	-	-	DR	-	GU27923386	1
	Decal set	-	-	-	DA	-	GU27923387	1
27	Toolkit	-	-	-	-	-	GU28929940	1
28	Shock abs. adj. Wrench	-	-	-	-	-	GU19912700	1
29	Gasket	-	-	-	-	-	GU27105885	1







Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Clutch control lever	-	-	-	-	GU27605510	1	
2	Clutch lever	-	-	-	-	GU27605715	1	
3	Screw	-	-	-	-	GU27601215	2	
4	U-bolt	-	-	-	-	GU27601015	1	
5	Register	-	-	-	-	GU27602515	1	
6	Protection	-	-	-	-	GU27663815	1	
7	Starter lever	-	-	-	-	GU27659415	1	
8	LH lights selector	-	-	-	-	GU27738015	1	
9	LH hand grip	-	-	-	-	GU27603015	1	
10	Clutch cable	-	-	-	-	GU27093036	1	
11	Choke cable	-	-	-	-	GU27132815	1	
12	Splitter	-	-	-	-	GU39607900	2	
13	Choke cable	-	-	-	-	GU27133536	2	
14	Cap	-	-	-	-	GU12717600	2	
15	Mobile body	-	-	-	-	GU27603815	1	
16	Steering block	-	-	-	-	GU27604415	1	
17	Throttle	-	-	-	-	GU27738815	1	
18	RH hand grip	-	-	-	-	GU27603515	1	
19	Adjuster screw	-	-	-	-	GU27603715	1	
20	Cap	-	-	-	-	GU27117615	1	
21	Gas lever transmission	-	-	-	-	GU27117536	1	
22	Throttle cable	-	-	-	-	GU23117730	2	
23	Brake m.cyl., w/ reservoir	-	-	-	-	GU27660215	1	
24	Pump cover	-	-	-	-	GU27661115	1	
25	Brake mast.cyl rev. kit	-	-	-	-	GU27659315	1	
26	Brake lever	-	-	-	-	GU27605615	1	
27	Pin	-	-	-	-	GU27604815	1	
28	Cap	-	-	-	-	GU27663875	1	
29	Bracket	-	-	-	-	GU27664075	1	
30	Brake light switch	-	-	-	-	GU27749815	1	
31	Self-tap screw	-	-	-	-	GU99210213	2	
32	Ball	-	-	-	-	GU92295708	1	




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Transmission housinggrey	-	-	-	-	GU31350380	1	
2	Clearance washer	-	-	-	-	GU19351900	1	
3	Gasket ring	-	-	-	-	GU70403547	11	
4	Clearance washer	-	-	-	-	GU19351100	1	
5	Roller bearing 35x50x17	-	-	-	-	GU92252235	1	
6	Oil plug	-	-	-	-	GU12022600	1	
7	O-ring 20,24X2,62	-	-	-	-	GU90706203	1	
8	Oil unload plug M10X1	-	-	-	-	GU31003766	1	
9	Gasket	-	-	-	-	GU10528900	1	
10	Breather plug	-	-	-	-	GU19206501	1	
11	Gasket	-	-	-	-	GU10528900	1	
12	Stud bolt	-	-	-	-	GU96508055	1	
13	Cover	-	-	-	-	GU19350421	1	
14	Ball bearing 70x110x13	-	-	-	-	GU92201070	1	
15	Gasket ring 75x90x8	-	-	-	-	GU90407590	1	
16	Pin	-	-	-	-	GU19351402	1	
17	Stop ring	-	-	-	-	GU90353030	1	
18	Bevel gear Z=8/31	-	-	-	-	GU19354621	1	
19	Screw	-	-	-	-	GU19356320	6	
20	Tap.roller bearing	-	-	-	-	GU92249223	1	
21	Spacer 1,2 mm	-	-	-	-	GU19355408	1	
	Spacer 1,6 mm	-	-	-	-	GU19355413	1	
	Spacer 1,5 mm	-	-	-	-	GU19355412	1	
	Spacer 1,3 mm	-	-	-	-	GU19355410	1	
	Spacer 1,1 mm	-	-	-	-	GU19355406	1	
	Spacer 1 mm	-	-	-	-	GU19355404	1	
	Spacer 0,9 mm	-	-	-	-	GU19355402	1	
	Spacer 0,8 mm	-	-	-	-	GU19355400	1	
	Spacer 1,4 mm	-	-	-	-	GU19355411	1	
22	Gasket	-	-	-	-	GU19350700	2	
23	Thrust washer	-	-	-	-	GU19352300	1	
24	Thrust washer	-	-	-	-	GU19353500	1	
25	Screw M8X25	-	-	-	-	GU19357660	7	



26	Spring washer 8x15x0,3	-	-	-	-	-	GU61270300	7
28	Rear brake disc	-	-	-	-	-	GU19635736	1
29	Washer 8,4X13X0,8	-	-	-	-	-	GU14615901	6
30	Screw	-	-	-	-	-	GU98054418	6
31	Bearing casing	-	-	-	-	-	GU19352401	1
32	Roller bearing 20x47x14	-	-	-	-	-	GU92249220	1
33	Spacer 1,2 mm	-	-	-	-	-	GU19355302	2
	Spacer 1,9 mm	-	-	-	-	-	GU19355309	2
	Spacer 1,8 mm	-	-	-	-	-	GU19355308	2
	Spacer 1,7 mm	-	-	-	-	-	GU19355307	2
	Spacer 1,6 mm	-	-	-	-	-	GU19355306	2
	Spacer 1,5 mm	-	-	-	-	-	GU19355305	2
	Spacer 1,3 mm	-	-	-	-	-	GU19355303	2
	Spacer 1,1 mm	-	-	-	-	-	GU19355301	2
	Spacer 1 mm	-	-	-	-	-	GU19355300	2
	Spacer 1,4 mm	-	-	-	-	-	GU19355304	2
34	Spacer	-	-	-	-	-	GU19355121	1
35	Shim 0,1 mm	-	-	-	-	-	GU19355200	1
36	Shim 0,15 mm	-	-	-	-	-	GU19355202	1
37	Spacer	-	-	-	-	-	GU19356801	1
38	Gasket ring 18,77X1,78	-	-	-	-	-	GU90706188	1
39	Nut	-	-	-	-	-	GU19356700	1
40	Gasket ring	-	-	-	-	-	GU90706552	1
41	Gasket ring	-	-	-	-	-	GU90403247	1
43	Nut M8X1,25	-	-	-	-	-	GU92602208	2
44	Spacer 1 mm	-	-	-	-	-	GU19355320	1
	Spacer 1,8 mm	-	-	-	-	-	GU19355328	1
	Spacer 1,7 mm	-	-	-	-	-	GU19355327	1
	Spacer 1,6 mm	-	-	-	-	-	GU19355326	1
	Spacer 1,5 mm	-	-	-	-	-	GU19355325	1
	Spacer 1,4 mm	-	-	-	-	-	GU19355324	1
	Spacer 1,3 mm	-	-	-	-	-	GU19355323	1
	Spacer 1,1 mm	-	-	-	-	-	GU19355321	1
	Spacer 1,9 mm	-	-	-	-	-	GU19355329	1
	Spacer 1,2 mm	-	-	-	-	-	GU19355322	1


		V 35 III 350 1985-1987	GU062	00	TAB N.	06		
DASHBOARD								
								
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Instrument plate	-	-	-	-	GU27764085	1	
2	Speedometer	-	-	-	-	GU27761535	1	
3	Speedometer transmission	-	-	-	-	GU27760410	1	
4	Tachometer	-	-	-	-	GU27767235	1	
5	Rev counter transmission	-	-	-	-	GU27768185	1	
6	Sheath	-	-	-	-	GU17762200	2	
7	Voltmeter	-	-	-	-	GU29784960	1	
8	Clock	-	-	-	T1	GU63783020	0	
	Fuel level sensor	-	-	-	-	GU27784685	1	
9	Dashboard	-	-	-	-	GU28766210	1	
10	Blinker indicator light holder	-	-	-	-	GU65758970	2	
11	Lamp 12V-1,2W	-	-	-	-	GU93450140	8	
12	Lampholder	-	-	-	-	GU19768680	8	
13	Decal "Aquila"	-	-	-	-	GU28769550	1	
14	Indicator light box	-	-	-	-	GU27766985	1	
15	Plate	-	-	-	-	GU28578600	1	
16	Screw	-	-	-	-	GU98054314	2	
17	Washer	-	-	-	-	GU95000206	2	
18	Notched washer	-	-	-	-	GU95021106	2	
19	Nut M8X1,25	-	-	-	-	GU92602208	2	
20	Lampholder	-	-	-	-	GU14768650	2	
21	Lamp 12v-3w	-	-	-	-	GU93450120	2	
22	Plate	-	-	-	-	GU27784485	2	
23	Hose clamp 2,4x92	-	-	-	-	GU49609601	4	
24	Rubber spacer	-	-	-	-	GU91551085	1	
25	Gear Z=14	-	-	-	-	GU14769200	1	
26	Rubber spacer	-	-	-	-	GU17765560	4	
27	Rubber spacer	-	-	-	-	GU17783960	4	

		V 35 III 350 1985-1987	GU062	00	TAB N.	07		
HEADLIGHT								
								
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Headlight	-	-	-	-	GU28740560	1	
2	Lamp 12V-4W	-	-	-	-	GU93450119	1	
3	Lamp 12V 45/40W	-	-	-	-	GU93450231	1	
4	Wiring	-	-	-	-	GU18720150	1	
5	Notched washer	-	-	-	-	GU95021105	3	
6	Nut	-	-	-	-	GU92602205	3	
7	Lampholder	-	-	-	-	GU14756255	1	
9	Rear turn indicator	-	-	-	-	GU28751650	2	
10	Lamp 12V-10W	-	-	-	-	GU93450129	2	
11	Turn indicator lens	-	-	-	-	GU28753750	2	
12	Turn indicator	-	-	-	-	GU28751300	2	
13	Washer	-	-	-	-	GU95007210	4	
14	Horn	-	-	-	-	GU61743700	1	
15	Nut M8X1,25	-	-	-	-	GU92602208	1	
16	Washer	-	-	-	-	GU95000208	1	
17	Spring washer	-	-	-	-	GU95021108	1	
18	Screw	-	-	-	-	GU98822440	1	
19	Spacer	-	-	-	-	GU91181016	1	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Taillight	-	-	-	-	GU27740985	1	
2	Lamp 12V/5-21W	-	-	-	-	GU93450224	2	
4	Gasket	-	-	-	-	GU28439800	2	
5	Nut M6x1	-	-	-	-	GU92630206	2	
6	Washer 6,2X18X1	-	-	-	-	GU95100118	4	
7	Spacer	-	-	-	-	GU91180607	2	
8	Rubber spacer	-	-	-	-	GU91551085	2	
9	Lamp 12V-10W	-	-	-	-	GU93450129	2	
10	Turn indicator lens	-	-	-	-	GU28733750	2	
11	Rear turn indicator supp.	-	-	-	-	GU28751750	2	
12	Washer	-	-	-	-	GU95007210	2	
14	Notched washer	-	-	-	-	GU95021110	2	
15	Nut	-	-	-	-	GU92602410	2	
16	Rear turn indicator	-	-	-	-	GU28751650	2	
17	Hose clamp 3,6x20,6	-	-	-	-	GU14609650	10	
18	Hose clamp 2,4x92	-	-	-	-	GU49609601	4	

		V 35 III 350 1985-1987		GU062	00	TAB N.	09	
		AIR FILTER						
								
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Intake manifold	-	-	-	-	GU19114300	1	
2	Hose clamp	-	-	-	-	GU93305092	1	
3	Pipe	-	-	-	-	GU17114650	1	
4	Breather pipe	-	-	-	-	GU95985532	1	
5	Hose clamp 3,6x20,6	-	-	-	-	GU14609650	1	
6	Air filter support	-	-	-	-	GU19155775	1	
7	Front hose	-	-	-	-	GU19156701	1	
8	Gasket	-	-	-	-	GU19113900	1	
9	Gasket ring	-	-	-	-	GU90706552	2	
10	Rear hose	-	-	-	-	GU19156900	1	
11	Breather pipe	-	-	-	-	GU19156001	1	
12	Ring	-	-	-	-	GU17113450	1	
13	Air filter	-	-	-	-	GU17113651	1	
14	Filter cover	-	-	-	-	GU17114050	1	
15	Support plate	-	-	-	-	GU27114120	1	
16	Washer 5,25x14x1,5	-	-	-	-	GU95100059	1	
17	Nut	-	-	-	-	GU92670305	1	




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Lower plate	-	-	-	-	GU62494021	1	
2	Plug	-	-	-	-	GU17517700	1	
3	Hex screw M10X55	-	-	-	-	GU98072555	2	
4	Washer	-	-	-	-	GU95007210	2	
5	Spacer	-	-	-	-	GU91181016	2	
6	Washer	-	-	-	-	GU62493200	1	
7	Upper plate	-	-	-	-	GU27493135	1	
8	Screw	-	-	-	-	GU98610540	2	
9	Screw	-	-	-	-	GU98612535	1	
10	Bush	-	-	-	-	GU17516600	1	
11	RH slider	-	-	-	-	GU27522535	1	
12	LH slider	-	-	-	-	GU27522635	1	
13	Oil seal	-	-	-	-	GU90403449	2	
14	Bush	-	-	-	-	GU27527620	2	
15	Screw	-	-	-	-	GU9862232005	2	
16	Washer 6,25x10x1,5	-	-	-	-	GU95100116	4	
17	Boom	-	-	-	-	GU27525420	2	
18	Dust cover	-	-	-	-	GU14524500	2	
19	Shock absorber	-	-	-	-	GU27526420	2	
20	Nut	-	-	-	-	GU92602308	2	
21	End stop	-	-	-	-	GU27527520	2	
22	Spring	-	-	-	-	GU27526620	2	
23	Screw	-	-	-	-	GU98620545	2	
24	Screw 25 mm	-	-	-	-	GU98622525	2	
25	Bored screw	-	-	-	-	GU28556450	1	
26	Air valve	-	-	-	-	GU28556250	1	
27	Gasket ring	-	-	-	-	GU90706266	2	
28	Copper washer	-	-	-	-	GU28556350	4	
29	Front shock absorber tube	-	-	-	-	GU19529660	1	
30	Nut	-	-	-	-	GU92781100	2	
31	Ring	-	-	-	-	GU17492700	4	
32	Flat washer	-	-	-	-	GU27499120	2	
33	RH slider	-	-	-	-	GU27496185	1	
34	LH slider	-	-	-	-	GU27496285	1	


36	O-ring 9x2	-	-	-	-	-	GU90706094	2
37	Anti-rubbing pipe	-	-	-	-	-	GU27526320	2
38	Handlebar collar	-	-	-	-	-	GU17500200	2
39	Stud bolt 8x46	-	-	-	-	-	GU96508045	2
40	Spring washer	-	-	-	-	-	GU95021108	2
41	Nut M8X1,25	-	-	-	-	-	GU92602208	2
42	Nut	-	-	-	-	-	GU92781081	2
43	Screw	-	-	-	-	-	GU98052499	2
44	Washer	-	-	-	-	-	GU95000208	2





Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Swing arm	-	-	-	-	GU19540261	1	
2	Hose	-	-	-	-	GU19327701	1	
3	Hose	-	-	-	-	GU19328801	1	
4	Circlip	-	-	-	-	GU90272023	1	
5	Disc	-	-	-	-	GU19327601	1	
6	Spring	-	-	-	-	GU94321099	1	
7	Coupling	-	-	-	-	GU19328061	1	
8	Protection collar	-	-	-	-	GU19548001	1	
9	Spring	-	-	-	-	GU19548101	1	
10	Clamp	-	-	-	-	GU93305078	1	
11	Plug	-	-	-	-	GU93180105	2	
12	Pin	-	-	-	-	GU19547000	21	
13	Spacer	-	-	-	-	GU35214300	2	
14	Nut	-	-	-	-	GU14547800	1	
16	Screw	-	-	-	-	GU98052550	1	
17	Washer 10,2x18x2	-	-	-	-	GU95004210	1	
18	Nut	-	-	-	-	GU92602210	1	
19	Nut	-	-	-	-	GU92781081	4	
20	Washer 8,4X13X0,8	-	-	-	-	GU14615901	4	
21	Transmission box assy., grey	-	-	-	-	GU20350220	1	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Starter relay	-	-	-	-	GU19732500	1	
2	Screw	-	-	-	-	GU98054212	1	
3	Washer 5,25x14x1,5	-	-	-	-	GU95100059	2	
4	Nut	-	-	-	-	GU92602205	1	
5	Electronic control unit	-	-	-	-	GU23721494	2	
6	Flexible support	-	-	-	-	GU27723835	2	
7	H.T. wiring	-	-	-	-	GU31722140	1	
8	Fuse block	-	-	-	-	GU19743020	1	
9	Screw	-	-	-	-	GU98202525	1	
10	Fuse 16A	-	-	-	-	GU17742550	4	
11	Main wiring harness	-	-	-	CEV	GU27747136	1	
	Main wiring harness	-	-	-	-	GU27747135	1	
12	Main wiring harness	-	-	-	CEV	GU27747236	1	
	Main wiring harness	-	-	-	-	GU27747285	1	
13	Main wiring harness	-	-	-	-	GU27725885	1	
	Main wiring harness	-	-	-	S	GU27725886	1	
14	Flasher unit	-	-	-	-	GU17750520	1	
15	Block	-	-	-	-	GU17751200	1	
16	Hose clamp 3,6x20,6	-	-	-	-	GU14609650	10	
17	Cap	-	-	-	-	GU12717600	1	






Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Handlebar	-	-	-	-	GU27600385	1	
2	LH lights selector	-	-	-	-	GU28738040	1	
3	RH lights selector	-	-	-	-	GU28750340	1	
4	Hex socket screw M6x12	-	-	-	-	GU98692312	2	
5	Front brake lever assy	-	-	-	-	GU27605485	1	
6	Guide block	-	-	-	-	GU65604400	1	
7	Brake light switch	-	-	-	-	GU28741100	1	
8	Clutch lever control	-	-	-	-	GU28605500	1	
9	Throttle pipe	-	-	-	-	GU65603800	1	
10	Cover	-	-	-	-	GU28603600	1	
11	Screw	-	-	-	-	GU98250405	1	
12	RH hand grip	-	-	-	-	GU27603520	1	
13	LH hand grip	-	-	-	-	GU27603020	1	
14	Nut	-	-	-	-	GU28605100	1	
15	Ring	-	-	-	-	GU27603620	1	
16	Ring	-	-	-	-	GU27603120	1	
17	Plug	-	-	-	-	GU27605220	2	
18	Clutch cable	-	-	-	-	GU19093052	1	
19	Gas lever transmission	-	-	-	-	GU19117550	2	
20	Hose clamp 2,4x92	-	-	-	-	GU49609601	1	
21	Balancing assy	-	-	-	-	GU27602735	2	
22	Rubber spacer	-	-	-	-	GU91551085	4	

		V 35 III 350 1985-1987	GU062	00	TAB N.	14		
FOOT RESTS - LATERAL STAND								
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	RH cradle arm	-	-	-	-	GU23420380	1	
2	LH cradle arm	-	-	-	-	GU23422180	1	
3	Central stand	-	-	-	-	GU19430305	1	
4	Rubber pedal	-	-	-	-	GU13432640	1	
5	Lateral stand spring	-	-	-	-	GU12434001	2	
6	Screw	-	-	-	-	GU98054530	2	
7	Spacer	-	-	-	-	GU91181114	2	
8	Spring	-	-	-	-	GU94322215	1	
9	Washer	-	-	-	-	GU95000210	3	
10	Nut M10x1,5	-	-	-	-	GU92630510	2	
11	Side arm	-	-	-	-	GU19432060	1	
12	Lockup rubber	-	-	-	-	GU19433000	1	
13	Pin	-	-	-	-	GU99105129	1	
14	Spring	-	-	-	-	GU19434000	2	
18	Front RH footrest	-	-	-	-	GU28440710	1	
19	LH Foot rests	-	-	-	-	GU28441810	1	
20	Washer	-	-	-	-	GU95129115	2	
21	Adjuster screw	-	-	-	-	GU98074430	2	
22	Spring washer 8x15x0,3	-	-	-	-	GU61270300	2	
23	Nut	-	-	-	-	GU92601210	2	
24	Rubber pedal	-	-	-	-	GU28443201	2	
25	LH front footrest guard	-	-	-	-	GU27447520	2	
26	Rear footrest	-	-	-	-	GU27442320	2	
27	Screw	-	-	-	-	GU98231025	2	
28	Washer 10,5X21X1	-	-	-	-	GU14018400	2	
31	Bush	-	-	-	-	GU19017000	2	
32	Pin M10x250	-	-	-	-	GU53429500	1	
33	Washer 10,2x18x2	-	-	-	-	GU95004210	1	
34	Nut	-	-	-	-	GU92602210	1	
35	Screw	-	-	-	-	GU98052565	2	
36	Washer 10,2x18x2	-	-	-	-	GU95004210	2	
37	Nut	-	-	-	-	GU92602210	2	
38	Hex screw M6X22	-	-	-	-	GU98054322	1	
39	Nut	-	-	-	-	GU92602206	1	
40	Nut	-	-	-	-	GU92601208	2	




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Rear brake caliper	-	-	-	-	GU23653011	1	
2	Screw	-	-	-	-	GU98622422	2	
3	Spring washer 8x15x0,3	-	-	-	-	GU61270300	2	
4	Nut M8X1,25	-	-	-	-	GU92602208	2	
5	Rear brake cal. decal	-	-	-	-	GU19654900	1	
6	Connection	-	-	-	-	GU19668000	1	
7	Brake hose	-	-	-	-	GU19658660	1	
8	Oil pipe screw *	-	-	-	-	GU95990028	2	
9	Gasket	-	-	-	-	GU25656100	7	
10	Brake light switch	-	-	-	-	GU14657050	1	
11	Cap	-	-	-	-	GU12735100	1	
12	Pipe	-	-	-	-	GU27658720	1	
13	Eyelet	-	-	-	-	GU19436500	1	
14	Protection	-	-	-	-	GU17573860	1	
15	Hose clamp 3,6x20,6	-	-	-	-	GU14609650	3	
16	Brake hose	-	-	-	-	GU17658860	1	
17	LH front brake caliper Grimeca	-	-	-	29895C	GU31652265	1	
18	Brake caliper decal	-	-	-	-	GU19652700	1	
19	Screw	-	-	-	-	GU98622422	2	
20	Spring washer 8x15x0,3	-	-	-	-	GU61270300	2	
21	Washer 8,5X18X0,5	-	-	-	-	GU95100250	1	
	Washer 8,5X18X0,8	-	-	-	-	GU95100251	1	
22	Brake caliper rev. kit GRIMECA	-	-	-	29895C	GU66659031	1	
	Brake caliper rev. kit BREMBO	-	-	-	-	GU39659000	2	
23	Pins+spring BREMBO	-	-	-	-	GU39659100	2	
	Pins+spring GRIMECA	-	-	-	29895C	GU31659165	2	
24	Bleeder+cap BREMBO D.6	-	-	-	-	GU65659200	2	
	Bleeder+cap GRIMECA	-	-	-	29895C	GU31659265	1	
25	Brake caliper cover BREMBO	-	-	-	-	GU39654700	2	
	Brake caliper cover GRIMECA	-	-	-	29895C	GU31654765	1	
26	Pads pair GRIMECA	-	-	-	29895C	GU31654665	2	
	Pads pair BREMBO	-	-	-	-	GU27654610	2	



		V 35 III 350 1985-1987	GU062	00	TAB N.	16		
FRONT MASTER CILINDER								
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Front master cilinder	-	-	-	-	GU28660200	1	
2	Screw	-	-	-	-	GU98622214	2	
3	Pipe	-	-	-	-	GU27651735	1	
4	Oil pipe screw *	-	-	-	-	GU95990028	1	
5	Gasket	-	-	-	-	GU25656100	3	
6	Hose clamp	-	-	-	-	GU17658360	1	
7	Ring	-	-	-	-	GU17658260	1	
8	Screw	-	-	-	-	GU98280410	1	
9	Nut M4x0,7	-	-	-	-	GU92630104	1	
10	RH front brake caliper Grimeca	-	-	-	29895C	GU31652365	1	
11	Brake caliper decal	-	-	-	-	GU19652700	1	
12	Screw	-	-	-	-	GU98622422	2	
13	Washer 8,5X18X0,8	-	-	-	-	GU95100251	1	
	Washer 8,5X18X0,5	-	-	-	-	GU95100250	1	
14	Spring washer 8x15x0,3	-	-	-	-	GU61270300	2	
15	Cover	-	-	-	-	GU28661100	1	
16	Brake mast.cyl rev. kit	-	-	-	-	GU28659300	1	
17	Pads pair BREMBO	-	-	-	-	GU27654610	1	
	Pads pair GRIMECA	-	-	-	29895C	GU31654665	2	
18	Brake caliper rev. kit BREMBO	-	-	-	-	GU39659000	1	
	Brake caliper rev. kit GRIMECA	-	-	-	29895C	GU66659031	1	
19	Pins+spring BREMBO	-	-	-	-	GU39659100	1	
	Pins+spring GRIMECA	-	-	-	29895C	GU31659165	2	
20	Bleeder+cap BREMBO D.6	-	-	-	-	GU65659200	1	
	Bleeder+cap GRIMECA	-	-	-	29895C	GU31659265	1	
21	Brake caliper cover BREMBO	-	-	-	-	GU39654700	1	
	Brake caliper cover GRIMECA	-	-	-	29895C	GU31654765	1	
22	Cap	-	-	-	-	GU39663801	1	
23	Hex socket screw M8X25	-	-	-	-	GU98622425	1	
24	Cable-guide	-	-	-	-	GU23655770	1	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Rear brake lever	-	-	-	-	GU19677000	1	
2	Rubber spacer	-	-	-	-	GU14251001	1	
3	Spring washer	-	-	-	-	GU95129260	1	
4	Flat washer	-	-	-	-	GU95004215	1	
5	Split pin	-	-	-	-	GU95500227	1	
6	Change gear tie rod compl.	-	-	-	-	GU19475000	1	
7	Block	-	-	-	-	GU18257551	1	
8	Nut	-	-	-	-	GU92690073	1	
9	Circlip	-	-	-	-	GU90271003	1	
10	Pin	-	-	-	-	GU95770265	1	
11	Washer	-	-	-	-	GU95129110	1	
12	Split pin	-	-	-	-	GU95500222	1	
13	Rear master cylinder	-	-	-	-	GU31666990	1	
14	Rear brake lever	-	-	-	-	GU19667500	1	
15	Rear brake lever spring	-	-	-	-	GU19667600	1	
16	Washer 6,15x11x0,8	-	-	-	-	GU95004206	1	
17	Screw	-	-	-	-	GU98054330	2	
18	Washer	-	-	-	-	GU95000206	2	
19	Notched washer	-	-	-	-	GU95021106	2	
20	Nut	-	-	-	-	GU92602206	2	
21	Brake oil tank	-	-	-	-	GU65663500	1	
23	Tank cap	-	-	-	-	GU17661052	1	
24	Oil pipe	-	-	-	-	GU00823950050	1	
25	Hose clamp	-	-	-	-	GU19157800	2	
26	Screw	-	-	-	-	GU98054216	2	
27	Washer 5,25x14x1,5	-	-	-	-	GU95100059	2	
28	Pump connection overhaul unit	-	-	-	-	GU19659500	1	
29	Lever overhaul kit	-	-	-	-	GU19659600	1	
30	Pump revision kit	-	-	-	-	GU17659350	1	
31	Spacer 7X12X5	-	-	-	-	GU91180705	2	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Front wheel, white	-	-	-	-	GU27610337	1	
	Front wheel, lt.grey	-	-	-	-	GU66610320	1	
	Front wheel, dk.grey	-	-	-	-	GU27610336	1	
2	Bearing	-	-	-	-	GU92204217	2	
3	Spacer	-	-	-	-	GU19615335	1	
4	Brake disc	-	-	-	-	GU31613380	2	
5	Screw	-	-	-	-	GU98052480	6	
6	Cap nut	-	-	-	-	GU92730082	6	
7	Washer	-	-	-	-	GU95000208	12	
8	Front wheel spindle	-	-	-	-	GU62614120	1	
9	Washer 17X27X2	-	-	-	-	GU95004217	1	
10	Nut M16X1,5	-	-	-	-	GU92602516	1	
11	Counterweight	-	-	-	-	GU14616150	2	
12	Spacer	-	-	-	-	GU62616320	1	
13	Spacer	-	-	-	-	GU91181803	1	
14	Flange	-	-	-	-	GU27616335	2	
15	Odometer gear 20/11	-	-	-	-	GU66762520	1	

	V 35 III 350 1985-1987	GU062	00	TAB N.	19
	REAR WHEEL				
					



Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Rear wheel, lt.grey	-	-	-	-	GU27630687	1	
	Rear wheel, dk.grey	-	-	-	-	GU27630686	1	
	Rear wheel, white	-	-	-	-	GU27630636	1	
2	RH rubber coupling	-	-	-	-	GU19632501	6	
3	LH rubber coupling	-	-	-	-	GU19632502	6	
4	Bearing	-	-	-	-	GU92204218	1	
5	Bearing	-	-	-	-	GU92204217	1	
6	Bearing internal spacer	-	-	-	-	GU19633935	1	
7	Rear wheel spindle	-	-	-	-	GU19633360	1	
8	Washer	-	-	-	-	GU14634400	1	
9	Nut M6X1,5	-	-	-	-	GU92602316	1	
10	Protection	-	-	-	-	GU19636400	1	
11	Counterweight	-	-	-	-	GU14616150	1	
12	Spacer	-	-	-	-	GU19634100	1	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Front fork assy	-	-	-	-	GU27490335	1	
2	Rear shock absorber	-	-	-	-	GU31999240	2	
3	Pin	-	-	-	-	GU19555200	1	
4	Pin	-	-	-	-	GU19555260	1	
5	Spacer	-	-	-	-	GU91181407	3	
6	Spacer	-	-	-	-	GU95100235	4	
7	Screw	-	-	-	-	GU98822416	4	
8	Plug	-	-	-	-	GU61514940	1	
9	Plug	-	-	-	-	GU39515000	2	
10	Steering race	-	-	-	00201N	GU61515240	1	
11	Ball	-	-	-	-	GU92295704	44	
12	Guard	-	-	-	-	GU62497820	1	
13	Decal "Aquila"	-	-	-	-	GU29482000	1	
14	Clamp	-	-	-	-	GU28578810	1	
15	Screw	-	-	-	-	GU98326016	1	
16	Hex screw M6X20	-	-	-	-	GU98054320	1	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Frame	-	-	-	-	GU27400135	1	
2	Lock	-	-	-	-	GU19782520	1	
3	Grommet	-	-	-	-	GU91551092	4	
4	Screw 25 mm	-	-	-	-	GU98622525	4	
5	Washer	-	-	-	-	GU95120105	4	
6	Nut	-	-	-	-	GU92602210	4	
7	Plate	-	-	-	-	GU27418210	1	
8	Screw	-	-	-	-	GU98054418	4	
9	Washer	-	-	-	-	GU95004208	4	
10	Disc	-	-	-	-	GU39103500	2	
11	Spacer	-	-	-	-	GU91180716	2	
12	Screw	-	-	-	-	GU98054325	2	
13	Washer 6,15x11x0,8	-	-	-	-	GU95004206	2	
14	Nut M6x1	-	-	-	-	GU92630106	2	
15	Drift	-	-	-	-	GU39103400	2	
16	Rubber spacer	-	-	-	-	GU27109085	2	
17	Drift	-	-	-	-	GU14107100	1	
18	Hose clamp 3,6x20,6	-	-	-	-	GU14609650	3	
19	Rubber spacer	-	-	-	-	GU27108935	2	
20	Pin M10x205	-	-	-	-	GU98110199	1	
21	Washer 10,2x18x2	-	-	-	-	GU95004210	3	
22	Nut	-	-	-	-	GU92602210	2	
23	Screw	-	-	-	-	GU98052555	2	

		V 35 III 350 1985-1987		GU062	00	TAB N.	22	
		DRIVE SHAFT						
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Crankshaft cpl.	-	-	-	-	GU19064121	1	
2	Plug	-	-	-	-	GU19065400	1	
3	Connecting rod	-	-	-	-	GU19061521	2	
4	Screw	-	-	-	-	GU19062221	4	
6	Bearing half-shell	-	-	-	-	GU19062022	4	
7	Front main half-bearing	-	-	-	-	GU19065623	2	
8	Rear main half-bearing	-	-	-	-	GU19066522	2	
9	Shoulder	-	-	-	-	GU31066480	2	
10	Piston	-	-	-	-	GU19060421	2	
11	Piston ring	-	-	-	-	GU19060700	4	
12	Piston ring	-	-	-	-	GU19061000	2	
13	Piston pin	-	-	-	-	GU19061220	2	
14	Stop ring	-	-	-	-	GU19061320	4	
15	Pistonring set	-	-	-	-	GU19060600	2	
16	Bush	-	-	-	-	GU19061821	2	
17	Screw	-	-	-	-	GU19067700	6	
18	Washer 8,4X13X0,8	-	-	-	-	GU14615901	6	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Carburettor RH	-	-	-	-	GU27112635	1	
2	Carburettor LH	-	-	-	-	GU27112636	1	
3	RH manifold	-	-	-	-	GU19115035	1	
4	LH manifold	-	-	-	-	GU19115036	1	
5	Gasket	-	-	-	-	GU19115520	2	
6	Screw	-	-	-	-	GU98310610	2	
7	Washer 6,25x10x1,5	-	-	-	-	GU95100116	2	
8	Screw	-	-	-	-	GU98822325	4	
9	Special washer	-	-	-	-	GU61013800	4	
10	Hose	-	-	-	-	GU19114320	2	
11	Hose clamp 32X52X8	-	-	-	-	GU93305032	4	
12	Gasket ring	-	-	-	-	GU90706315	2	
13	Manifold	-	-	-	-	GU19114400	2	
14	Starter	-	-	-	-	GU23133100	1	
15	RH choke cable	-	-	-	-	GU19133560	1	
16	LH choke cable	-	-	-	-	GU19134000	1	
17	Hose clamp	-	-	-	-	GU19718000	2	
18	Washer	-	-	-	-	GU95004205	4	
19	Screw	-	-	-	-	GU98054214	4	
20	Hose clamp 3,6x20,6	-	-	-	-	GU14609650	2	
21	Float chamber fix.plug	-	-	-	-	GU27933720	2	




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Primary gear shaft Z=11	-	-	-	-	GU19210520	1	
2	Gear 5a AS Z=22	-	-	-	-	GU19212020	1	
3	Thrust washer mm1	-	-	-	-	GU19215420	5	
4	Circlip	-	-	-	-	GU90271220	5	
5	Gear 4a AS Z=22	-	-	-	-	GU19211820	1	
6	Gear 3a AS Z=18	-	-	-	-	GU19211420	1	
7	Thrust washer	-	-	-	-	GU19214620	1	
8	Gear	-	-	-	-	GU19211320	1	
9	Washer	-	-	-	-	GU19212800	1	
10	Ball bearing	-	-	-	-	GU92201415	1	
11	Clearance washer	-	-	-	-	GU39238100	1	
12	Nut	-	-	-	-	GU10054100	1	
13	Bearing 20X47X14	-	-	-	-	GU92201220	1	
14	Driven shaft	-	-	-	-	GU19213620	1	
15	Spacer	-	-	-	-	GU19212900	1	
16	Bearing 20X47X14	-	-	-	-	GU92201220	1	
17	Spacer	-	-	-	-	GU19213720	1	
18	Gasket ring 18,77X1,78	-	-	-	-	GU90706188	1	
19	Circlip	-	-	-	-	GU90271121	1	
20	Gear	-	-	-	-	GU19214501	1	
21	Gear	-	-	-	-	GU19214820	1	
22	Gear	-	-	-	-	GU19215121	1	
23	Gear	-	-	-	-	GU19215220	1	
24	Gear	-	-	-	-	GU19214001	1	
26	Spacer	-	-	-	-	GU35214300	2	
27	Ball bearing	-	-	-	-	GU92201415	1	
28	Change gear tie rod compl.	-	-	-	-	GU19257701	1	
29	Circlip	-	-	-	-	GU90271115	1	
30	Shift cam	-	-	-	-	GU19234420	1	
31	Pin	-	-	-	-	GU19234600	4	
32	Spacer 1 mm	-	-	-	-	GU19355300	1	
33	Snap ring	-	-	-	-	GU90271020	1	
34	Fork AP	-	-	-	-	GU19231220	1	

35	Fork AS	-	-	-	-	-	GU19231020	2
36	Roller	-	-	-	-	-	GU92297909	3
37	Pin	-	-	-	-	-	GU95520316	3
38	Pre-selector kit	-	-	-	-	-	GU20999520	1
39	Spring	-	-	-	-	-	GU60238200	1
40	Bush	-	-	-	-	-	GU91182010	1
41	Shift lever	-	-	-	-	-	GU19258220	1
42	Screw	-	-	-	-	-	GU98052325	2
43	Washer	-	-	-	-	-	GU95000206	2
44	Tie rod	-	-	-	-	-	GU18257950	1
45	Fork	-	-	-	-	-	GU12629800	1
46	Nut	-	-	-	-	-	GU95602206	2
47	Washer	-	-	-	-	-	GU95129110	1
49	Split pin	-	-	-	-	-	GU95500222	1
50	Pin	-	-	-	-	-	GU95770265	1
51	Lever	-	-	-	-	-	GU19256920	1
52	Spring washer	-	-	-	-	-	GU60013800	1
54	Gear lever	-	-	-	-	-	GU19252900	1
55	Rubber spacer	-	-	-	-	-	GU14251001	1
56	Spring washer	-	-	-	-	-	GU95129260	1
57	Intermediate gear Z=24	-	-	-	-	-	GU27211110	1
58	Bush	-	-	-	-	-	GU19266720	1
59	Clearance washer	-	-	-	-	-	GU39238100	1
60	Nut	-	-	-	-	-	GU10054100	1
61	Nut M6x1	-	-	-	-	-	GU92630106	1
62	Ball joint	-	-	-	-	-	GU18258101	1
63	Washer	-	-	-	-	-	GU19214320	4





Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Gasket envelope	-	-	-	-	GU39939900	2	
2	Cap	-	-	-	01	000000	4	
3	Wire tensioner screw	-	-	-	-	GU53937200	2	
4	Nut	-	-	-	-	GU19938880	2	
5	Pipe	-	-	-	-	GU49938900	2	
6	Nut	-	-	-	-	GU12937300	4	
7	Screw	-	-	-	-	GU13937900	2	
8	Starter device cover	-	-	-	-	GU17937450	2	
9	Gasket	-	-	-	01	000000	2	
10	Valve spring	-	-	-	-	GU39937600	2	
11	Starter valve	-	-	-	-	GU13937800	2	
12	Adj.min.eng.speed screw	-	-	-	-	GU13936200	2	
13	Spring	-	-	-	-	GU13936300	2	
14	Gas valve adjuster screw	-	-	-	-	GU13936600	2	
15	Spring	-	-	-	-	GU13936700	2	
16	Screw	-	-	-	-	GU13932800	4	
17	Washer	-	-	-	-	GU13932900	4	
18	Valve cover	-	-	-	-	GU53935000	2	
19	Gasket	-	-	-	01	000000	2	
20	Wire tensioner screw	-	-	-	-	GU12937200	2	
21	Gas valve return spring	-	-	-	-	GU53937100	2	
22	Conical pin E27	-	-	-	-	GU25937701	2	
23	Conical pin clip	-	-	-	-	GU55938585	2	
24	Gas valve 40	-	-	-	-	GU61934800	2	
25	Starter jet	-	-	-	-	GU25936000	2	
26	Gasket	-	-	-	01	000000	2	
27	Needle valve 260AH	-	-	-	-	GU19935500	2	
28	Idle jet 40	-	-	-	-	GU19935900	2	
29	Gasket	-	-	-	01	000000	2	
30	Conical pin 8	-	-	-	-	GU19934960	2	
31	Fuel filter	-	-	-	-	GU73934000	2	
32	Fuel pipe union cap	-	-	-	-	GU13934600	2	
33	Gasket	-	-	-	01	000000	2	


34	Cap fixing screw	-	-	-	-	-	GU10934900	2
35	Float	-	-	-	-	-	GU61934300	2
36	Float pin	-	-	-	-	-	GU13933100	2
37	Gasket	-	-	-	O1	-	0000000	2
38	Float chamber	-	-	-	-	-	GU10934400	2
39	Gasket	-	-	-	O1	-	0000000	2
40	Main jet 108	-	-	-	-	-	GU19935701	2
41	Plug	-	-	-	-	-	GU13933700	2





Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Crankcase, blank	-	-	-	-	GU19000120	1	
2	Stud bolt	-	-	-	-	GU96451560	4	
3	Stud bolt	-	-	-	-	GU96451430	4	
4	Stud bolt	-	-	-	-	GU96508055	2	
5	Bush	-	-	-	-	GU19015020	4	
6	Spring washer 8x15x0,3	-	-	-	-	GU61270300	6	
7	Nut M8X1,25	-	-	-	-	GU92602208	6	
8	Union	-	-	-	-	GU19003800	1	
9	Bush 6,6x9x13	-	-	-	-	GU19002020	2	
10	Plug	-	-	-	-	GU19016320	1	
11	Gasket ring	-	-	-	-	GU90401530	1	
13	Gasket ring	-	-	-	-	GU90405367	1	
14	Timing system cover, blank	-	-	-	-	GU19001420	1	
15	Gasket	-	-	-	-	GU19001200	1	
16	Hex socket screw M6X25	-	-	-	-	GU98622325	22	
17	Plug	-	-	-	-	GU19017120	1	
18	Gasket ring 28x38x7	-	-	-	-	GU90402840	1	
19	Motor oil cup	-	-	-	-	GU19003502	1	
	Oil sump black	-	-	-	M3	GU27003550	1	
	Engine oil sump, blank	-	-	-	M3	GU27003585	1	
20	Gasket	-	-	-	-	GU19003602	1	
21	Oil unload plug M10X1	-	-	-	-	GU31003766	1	
22	Gasket	-	-	-	-	GU10528900	1	
23	Screw M6X35	-	-	-	-	GU98620335	5	
24	Cover	-	-	-	-	GU27001636	1	
25	Flange	-	-	-	-	GU27001136	1	
26	Cover, blank	-	-	-	-	GU19003400	1	
27	O-ring	-	-	-	-	GU90706444	1	
28	Oil filler plug	-	-	-	-	GU19004920	1	
	Oil load plug	-	-	-	M3	GU27004985	1	
29	Gasket ring	-	-	-	-	GU90706282	1	
30	Oil unload plug	-	-	-	-	GU12003702	1	
31	Gasket 20,1x28x2	-	-	-	-	GU95100709	1	


32	Bolt	-	-	-	M3	-	GU27152885	1
	Screw m8x90	-	-	-	-	-	GU98052490	1
33	Gasket 8,25x15x1	-	-	-	-	-	GU12154200	1
34	Oil seals - set	-	-	-	-	-	GU19999580	1
35	Engine set gasket	-	-	-	-	-	GU19999020	1
36	Column nut	-	-	-	-	-	GU92660010	4
37	Screw M6X30	-	-	-	-	-	GU98620330	2
38	Washer 10,5X18X0,8	-	-	-	-	-	GU95129180	4
39	Engine w/o gearbox, blank	-	-	-	-	-	GU27991035	1

		V 35 III 350 1985-1987	GU062	00	TAB N.	27		
		CYLINDER HEAD						
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	RH head	-	-	-	-	GU19022120	1	
2	LH head	-	-	-	-	GU19022220	1	
3	Valve guide	-	-	-	-	GU61036801	4	
4	Snap ring	-	-	-	-	GU90353009	4	
5	Stud bolt	-	-	-	-	GU96506042	4	
6	Anti-vibration plate	-	-	-	-	GU19025300	4	
7	Nut	-	-	-	-	GU19021920	2	
8	Oil seal	-	-	-	-	GU19037820	4	
9	Valves cover	-	-	-	-	GU19023520	2	
10	Gasket	-	-	-	-	GU19023700	2	
11	Nut M10X1,5	-	-	-	-	GU92603010	4	
12	Column nut	-	-	-	-	GU13021900	4	
13	Washer 10,5X18X0,8	-	-	-	-	GU95129180	4	
14	Stud bolt	-	-	-	-	GU96510182	4	
15	Stud bolt 125 mm	-	-	-	-	GU96510125	4	
16	Hex socket screw M6X25	-	-	-	-	GU98622325	12	
17	Cylinder with piston	-	-	-	-	GU19060121	2	
18	Bush	-	-	-	-	GU19021320	2	
19	Cylinder head gasket	-	-	-	-	GU27022020	2	
20	Stud bolt	-	-	-	-	GU96508107	2	
21	Spring washer 8x15x0,3	-	-	-	-	GU61270300	2	
22	Plug	-	-	-	-	GU93180245	4	
23	O-ring	-	-	-	-	GU61027200	2	
24	Gasket	-	-	-	-	GU19020820	2	
25	Nut	-	-	-	-	GU92601010	1	
26	Washer 10,5X18X0,8	-	-	-	-	GU95129180	1	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Intake valve	-	-	-	-	GU19036021	2	
2	Exhaust valve	-	-	-	-	GU23036100	2	
3	Spring	-	-	-	-	GU61037600	4	
4	Spring	-	-	-	-	GU61037500	4	
5	Upper cup	-	-	-	-	GU61038000	4	
6	Half-cone	-	-	-	-	GU61038100	8	
7	Rocker arm assy.	-	-	-	-	GU19030500	4	
8	Screw	-	-	-	-	GU19034000	4	
9	Nut M6x1	-	-	-	-	GU92602406	4	
10	Rocker shaft	-	-	-	-	GU19032000	2	
11	Clearance washer	-	-	-	-	GU19032300	4	
12	Circlip	-	-	-	-	GU90271018	4	
13	Lower cup	-	-	-	-	GU61037000	4	
14	Spacer	-	-	-	-	GU19032980	4	
15	Hose	-	-	-	-	GU19027500	2	
16	Camshaft	-	-	-	M2	GU27053463	1	
	Camshaft	-	-	-	M1	GU19053320	1	
17	Timing system gear	-	-	-	-	GU19054521	1	
18	Bolt	-	-	-	-	GU61054900	2	
19	Camshaft chain	-	-	-	-	GU19058021	1	
20	Chain stretching drive	-	-	-	-	GU19058220	1	
21	Screw	-	-	-	-	GU98822316	1	
22	Washer	-	-	-	-	GU95129115	1	
23	Sector	-	-	-	-	GU19055700	2	
24	Snap ring	-	-	-	-	GU90353029	1	
25	Tappet	-	-	-	-	GU19045861	4	
26	Rocker arm rod	-	-	-	-	GU19045020	4	
27	Roller	-	-	-	-	GU95512035	1	
28	Safety washer	-	-	-	-	GU23217800	2	


		V 35 III 350 1985-1987	GU062	00	TAB N.	29		
CLUTCH								
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Clutch control	-	-	-	-	GU19080161	1	
2	New cup type	-	-	-	-	GU19083462	1	
3	Snap ring	-	-	-	-	GU90272075	1	
4	Driven clutch disc	-	-	-	-	GU27084420	1	
5	Chain ring MOTOPLAT	-	-	-	-	GU19067900	1	
6	Washer 6,4x10x0,7	-	-	-	-	GU14217901	6	
7	Hex screw M6X16	-	-	-	-	GU98054316	6	
8	Rod	-	-	-	-	GU20085720	1	
9	Inner body	-	-	-	-	GU14086000	1	
10	Thrust bearing	-	-	-	-	GU12087001	1	
11	Outer body	-	-	-	-	GU14086100	1	
12	O-ring 17,13x2,62	-	-	-	-	GU90706170	1	
13	Clutch release shaft	-	-	-	-	GU14090201	1	
14	Adjuster screw	-	-	-	-	GU14090400	1	
15	Nut M8X1	-	-	-	-	GU92602508	1	
16	Lever return spring	-	-	-	-	GU94321105	1	
17	Pin 7x39	-	-	-	-	GU95780271	1	
18	Split pin	-	-	-	-	GU95500222	1	
19	Gasket ring 28x40x7	-	-	-	-	GU90402841	1	
20	Gasket ring	-	-	-	-	GU27210710	1	
21	Gasket ring 6x16x7	-	-	-	-	GU90400616	1	
22	Spacer	-	-	-	-	GU19213720	1	
23	Gasket ring 18,77X1,78	-	-	-	-	GU90706188	1	
24	Nut	-	-	-	-	GU19356700	1	
26	Clutch drum	-	-	-	-	GU19200422	1	
27	Plug	-	-	-	-	GU93180220	1	
28	Bearing	-	-	-	-	GU92201222	1	
29	Bearing fixing plate	-	-	-	-	GU19203420	1	
30	Screw	-	-	-	-	GU98054314	3	
31	Washer 6,4x10x0,7	-	-	-	-	GU14217901	3	
32	Screw M6X30	-	-	-	-	GU98620330	11	
33	Screw M8X35	-	-	-	-	GU98620435	3	
34	Screw	-	-	-	-	GU98620450	1	
35	Spring washer 8x15x0,3	-	-	-	-	GU61270300	6	
36	Nut M8X1,25	-	-	-	-	GU92602208	1	
37	Screw M8X40	-	-	-	-	GU98620440	2	



Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	RH exhaust pipe	-	-	-	-	GU19120735	1	
2	LH exhaust pipe	-	-	-	-	GU19120736	1	
3	Exhaust pipe	-	-	-	-	GU19121135	1	
4	Hose clamp	-	-	-	-	GU61126920	2	
5	Gasket	-	-	-	-	GU19025280	2	
6	Spacer	-	-	-	-	GU61025400	4	
7	Exhaust ring nut	-	-	-	-	GU19121050	2	
8	Special washer	-	-	-	-	GU61013800	4	
9	Nut	-	-	-	-	GU92701062	4	
10	LH silencer	-	-	-	-	GU19122936	1	
11	RH silencer	-	-	-	-	GU19123036	1	
12	Hose clamp	-	-	-	-	GU19123435	2	
13	RH plate	-	-	-	-	GU19128660	1	
14	LH plate	-	-	-	-	GU19128760	1	
15	Spring washer 8x15x0,3	-	-	-	-	GU61270300	4	
16	Nut M8X1,25	-	-	-	-	GU92602208	4	
17	Hex screw M10X35	-	-	-	-	GU98054535	2	
18	Notched washer	-	-	-	-	GU95021110	4	
19	Nut	-	-	-	-	GU92602410	2	
20	Screw	-	-	-	-	GU61127520	2	
21	Ring nut	-	-	-	-	GU61127220	2	



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Oil pump	-	-	-	-	GU19146420	1	
3	Roller bearing 10x22x20	-	-	-	-	GU92252210	1	
4	Oil pump shaft assy.	-	-	-	-	GU19147820	1	
5	Inner rotor	-	-	-	-	GU19148420	1	
6	Outer rotor	-	-	-	-	GU19148620	1	
7	Guide roller	-	-	-	-	GU92296726	1	
8	Oil pump gear	-	-	-	-	GU19147721	1	
9	Washer 10,5x16x1	-	-	-	-	GU19149800	1	
10	Nut M10x1,25	-	-	-	-	GU92602510	1	
11	Screw M6X35	-	-	-	-	GU98620335	3	
12	Pin	-	-	-	-	GU19018920	2	
13	Oil filter	-	-	-	-	GU19152200	1	
14	Screw	-	-	-	-	GU98054314	1	
15	Plate	-	-	-	-	GU95187006	1	
16	Oil filter	-	-	-	-	GU19153000	1	
	Oil filter	-	-	-	M3	GU27153085	1	
17	Oil valve cpl.	-	-	-	-	GU10158201	1	
18	Valve body	-	-	-	-	GU10158701	1	
19	Piston	-	-	-	-	GU12150900	1	
20	Valve spring	-	-	-	-	GU94321072	1	
21	Bottom	-	-	-	-	GU12150700	1	
22	Washer 14,5X20X1	-	-	-	-	GU95100523	2	
23	Plug	-	-	-	-	GU12159000	1	
24	Pressure sensor	-	-	-	02201N	GU31999581	1	
29	Breather pipe	-	-	-	-	GU19159600	1	
30	Hose clamp	-	-	-	-	GU61108400	3	
31	Hose clamp	-	-	-	-	GU28157850	1	
32	Breather	-	-	-	B	GU19159300	1	
33	Gasket 8,25x15x1	-	-	-	-	GU12154200	2	
34	Ball	-	-	-	-	GU92295911	1	



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Box cover	-	-	-	-	GU19200821	1	
2	Bearing 15x35x11	-	-	-	-	GU92204215	2	
3	Gasket ring 28x40x7	-	-	-	-	GU90402841	1	
4	O-ring 13,95x2,92	-	-	-	-	GU90706140	1	
5	Plate	-	-	-	-	GU19213820	1	
6	Screw	-	-	-	-	GU98622314	4	
7	Washer 6,4x10x0,7	-	-	-	-	GU14217901	6	
8	Plate	-	-	-	-	GU19235800	1	
9	Screw	-	-	-	-	GU98622314	2	
10	Gasket	-	-	-	-	GU19200320	1	
11	Sensor	-	-	-	-	GU19207220	1	
12	Gasket 8,25x15x1	-	-	-	-	GU12154200	1	
13	Screw M12x1,25	-	-	-	-	GU19237800	1	
14	Low nut M12x1,25	-	-	-	-	GU92602512	1	
15	Gasket	-	-	-	-	GU19201120	1	
16	Bush 6,6x9x13	-	-	-	-	GU19002020	4	
17	Transmission cage	-	-	-	-	GU19200222	1	
18	Screw M6X30	-	-	-	-	GU98620330	7	
19	Screw M8X35	-	-	-	-	GU98620435	4	
20	Pawl	-	-	-	-	GU55234700	1	
21	Lever return spring	-	-	-	-	GU94321067	1	
22	Breather plug	-	-	-	-	GU19206501	1	
23	Gasket	-	-	-	-	GU10528900	2	
24	Oil plug	-	-	-	-	GU12022600	1	
25	O-ring 20,24X2,62	-	-	-	-	GU90706203	1	
26	Oil unload plug M10X1	-	-	-	-	GU31003766	1	
27	Oil bulhead	-	-	-	-	GU19208220	1	
28	Ball bearing 20x42x12	-	-	-	-	GU92201120	1	
29	Transmission assy and housing	-	-	-	-	GU27991535	1	