



- KEY**
- 1 MULTIPLE CONNECTORS
 - 2 CLUTCH SWITCH
 - 3 START-UP RELAY
 - 4 START-UP MAINTENANCE RELAY
 - 5 LIGHT LOGIC RELAY
 - 6 FOG LIGHTS RELAY
 - 7 RIGHT LIGHT SWITCH
 - 8 LEFT LIGHT SWITCH
 - 9 HORN
 - 10 AMBIENT AIR TEMPERATURE SENSOR
 - 11 INSTRUMENT PANEL
 - 12 IMMOBILIZER AERIAL
 - 13 KEY SWITCH
 - 14 HEATED HANDGRIPS
 - 15 GPS COUPLING
 - 16 ELECTRIC LOCK
 - 17 REAR RIGHT TURN INDICATOR
 - 18 REAR LIGHT ASSEMBLY
 - 19 REAR LEFT TURN INDICATOR
 - 20 LICENSE PLATE LIGHT BULB
 - 21 REAR STOP SWITCH
 - 22 FRONT STOP SWITCH
 - 23 ECU DIAGNOSIS
 - 24 AUXILIARY FUSES
 - 25 STARTER MOTOR
 - 26 BATTERY
 - 27 POWER SUPPLY SOCKET
 - 28 MAIN FUSES
 - 29 GENERATOR
 - 30 MAIN INJECTION RELAY
 - 31 SECONDARY INJECTION RELAY
 - 32 OIL PRESSURE SENSOR
 - 33 NEUTRAL SENSOR
 - 34 LAMBDA PROBE
 - 35 SIDE STAND SWITCH
 - 36 FUEL RESERVE SENSOR
 - 37 FUEL PUMP
 - 38 INTAKE AIR TEMPERATURE SENSOR
 - 39 ENGINE TEMPERATURE SENSOR
 - 40 IDLE MOTOR
 - 41 THROTTLE POSITION SENSOR
 - 42 RIGHT CYLINDER OUTER SPARK PLUG
 - 43 LEFT CYLINDER OUTER SPARK PLUG
 - 44 RIGHT CYLINDER COIL
 - 45 LEFT CYLINDER COIL
 - 46 RIGHT CYLINDER INJECTOR
 - 47 LEFT CYLINDER INJECTOR
 - 48 SPEED SENSOR
 - 49 FALL SENSOR
 - 50 PICK UP
 - 51 ECU
 - 52 FOG LIGHTS
 - 53 FRONT LEFT TURN INDICATOR
 - 54 HEAD LIGHT ASSEMBLY
 - 55 TAIL LIGHT BULB
 - 56 LOW-BEAM BULB
 - 57 HIGH-BEAM BULB
 - 58 FRONT RIGHT TURN INDICATOR
 - 59 INSTRUMENT PANEL DIAGNOSIS
 - 60 ANTI-THIEF DEVICE ECU (OPTIONAL)
 - 61 HELMET COMPARTMENT SWITCH
 - 62 GLOVE-BOX OPENING RELAY

- COLOUR KEY**
- Ar Orange
 - Az Sky blue
 - B Blue
 - Bi White
 - C Yellow
 - Gr Grey
 - M Brown
 - N Black
 - R Red
 - Ro Pink
 - V Green
 - Vi Purple

- DIAGRAM COLOURS - KEY**
- POWER SUPPLY
 - GROUND
 - ENABLING / SIGNAL
 - ENABLING / SIGNAL

- ECU CONNECTORS KEY**
- E Brown
 - V Blue

