

- KEY**
- 01 MULTIPLE CONNECTORS
 - 02 REVOLUTION SENSOR
 - 03 LOW OIL SENSOR
 - 04 LEFT CYLINDER COIL
 - 05 RIGHT CYLINDER COIL
 - 06 SPARK PLUGS
 - 07 LEFT CYLINDER INJECTOR
 - 08 RIGHT CYLINDER INJECTOR
 - 09 FUEL PUMP
 - 10 FUEL RESERVE SENSOR
 - 11 MAIN INJECTION RELAY (STOPRISED)
 - 12 SECONDARY INJECTION RELAY
 - 13 SIDE STAND SWITCH
 - 14 LAMBDA PROBE
 - 15 THROTTLE POSITION SENSOR
 - 16 INTAKE AIR TEMPERATURE SENSOR
 - 17 ENGINE TEMPERATURE SENSOR
 - 18 VOLTAGE REGULATOR
 - 19 PICK UP
 - 20 BATTERY
 - 21 STARTER MOTOR
 - 22 MAIN FUSES
 - 23 SECONDARY FUSES
 - 24 LICENSE PLATE LIGHT BULB
 - 25 REAR LEFT TURN INDICATOR
 - 26 TWIN-FILAMENT REAR / STOP BULB
 - 27 REAR LIGHT ASSEMBLY
 - 28 REAR RIGHT TURN INDICATOR
 - 29 KEY SWITCH
 - 30 FRONT STOP SWITCH
 - 31 REAR STOP SWITCH
 - 32 RIGHT LIGHT SWITCH
 - 33 LEFT LIGHT SWITCH
 - 34 HORN
 - 35 CLUTCH SWITCH
 - 36 START-UP RELAY
 - 37 LIGHT LOGIC RELAY
 - 38 -
 - 39 -
 - 40 DIODE
 - 41 GEAR IN NEUTRAL SWITCH
 - 42 FALL SENSOR
 - 43 INSTRUMENT PANEL
 - 44 VEHICLE SPEED SENSOR
 - 45 AIR TEMPERATURE SENSOR
 - 46 FRONT RIGHT TURN INDICATOR
 - 47 LOW-BEAM/HIGH-BEAM BULB
 - 48 TAIL LIGHT BULB
 - 49 HEAD LIGHT ASSEMBLY
 - 50 FRONT LEFT TURN INDICATOR
 - 51 ECU
 - 52 INSTRUMENT PANEL DIAGNOSIS

- COLOUR KEY**
- Ar Orange
 - Az Sky blue
 - B Blue
 - Bl White
 - C Yellow
 - Gr Grey
 - M Brown
 - N Black
 - R Red
 - Ro Pink
 - V Green
 - Vi Purple

- DIAGRAM COLOURS - KEY**
- POWER SUPPLY
 - GROUND
 - ENABLING / SIGNAL
 - ENABLING / SIGNAL

